

# OPERATOR'S MANUAL

**TMA VXI-27**

***plug & play* POWER MODULE CONTROLLER**

**INTERACTIVE DIGITALLY CONTROLLED  
POWER MODULE SYSTEM**

KEPCO INC.  
An ISO 9001 Company.

**MODEL  
TMA VXI-27  
*plug & play* POWER MODULE  
CONTROLLER**

ORDER NO.

REV. NO.

## IMPORTANT NOTES:

- 1) This manual is valid for the following Model and associated serial numbers:

MODEL	SERIAL NO.	REV. NO.
-------	------------	----------

- 2) A Change Page may be included at the end of the manual. All applicable changes and revision number changes are documented with reference to the equipment serial numbers. Before using this Instruction Manual, check your equipment serial number to identify your model. If in doubt, contact your nearest Kepco Representative, or the Kepco Documentation Office in New York, (718) 461-7000, requesting the correct revision for your particular model and serial number.
- 3) The contents of this manual are protected by copyright. Reproduction of any part can be made only with the specific written permission of Kepco, Inc.

Data subject to change without notice.

©2007, KEPCO, INC  
P/N 243-0886R8a



**KEPCO®**  
**THE POWER SUPPLIER™**

KEPCO, INC. • 131-38 SANFORD AVENUE • FLUSHING, NY. 11352 U.S.A. • TEL (718) 461-7000 • FAX (718) 767-1102  
email: [hq@kepcopower.com](mailto:hq@kepcopower.com) • World Wide Web: <http://www.kepcopower.com>



# TABLE OF CONTENTS

SECTION	PAGE
<b>SECTION 1 - INTRODUCTION</b>	
1.1	Scope of Manual ..... 1-1
1.2	General Description ..... 1-1
1.3	Specifications ..... 1-2
1.4	TMA VXI-27 Interconnections ..... 1-2
1.5	Accessories ..... 1-3
<b>SECTION 2 - INSTALLATION</b>	
2.1	Unpacking and Inspection ..... 2-1
2.2	Installation ..... 2-1
2.2.1	VXI Address Select ..... 2-1
2.3	Front Panel Terminations ..... 2-1
<b>SECTION 3 - OPERATION</b>	
3.1	Local Operation ..... 3-1
3.1.1	Front panel indicators ..... 3-1
3.1.2	Auxiliary Signals ..... 3-1
3.1.2.1	Emergency Output Shutdown ..... 3-1
3.1.2.2	Discrete Fault Line ..... 3-1
3.1.2.3	+5V Output ..... 3-2
3.2	Remote Operation ..... 3-2
3.3	VXI <i>plug&amp;play</i> Operation ..... 3-2
3.3.1	Background ..... 3-2
3.3.2	Driver Installation ..... 3-2
3.3.3	Operating the Soft Panel ..... 3-3
3.3.3.1	Understanding the Controls ..... 3-4
3.3.3.2	Select the Channel ..... 3-6
3.3.3.3	Set the Voltage/current ..... 3-6
3.3.3.4	Apply Programmed Settings to the Power Supply ..... 3-6
3.3.3.5	Enable the Power Supply Output ..... 3-6
3.4	VXIbus Communication ..... 3-6
3.4.1	Typical VXIbus Start-up Sequence ..... 3-8
3.5	SCPI Programming ..... 3-8
3.5.1	SCPI Messages ..... 3-8
3.5.2	Common Commands/Queries ..... 3-9
3.5.3	SCPI Subsystem Command/Query Structure ..... 3-9
3.5.4	Program Message Structure ..... 3-10
3.5.4.1	Keyword ..... 3-11
3.5.4.2	Keyword Separator ..... 3-12
3.5.4.3	Query Indicator ..... 3-12
3.5.4.4	Data ..... 3-12
3.5.4.5	Data Separator ..... 3-12
3.5.4.6	Message Unit Separator ..... 3-12
3.5.4.7	Root Specifier ..... 3-12
3.5.4.8	Message Terminator ..... 3-13
3.5.5	Understanding The Command Structure ..... 3-13
3.5.6	Addressing Multiple Power Supplies ..... 3-14
3.5.7	Understanding The Command Structure ..... 3-14
3.5.8	Program Message Syntax Summary ..... 3-15
3.5.9	Status Reporting ..... 3-15
3.5.9.1	STATUS REPORTING STRUCTURE ..... 3-16
3.5.9.2	Operational Status Register ..... 3-16
3.5.9.3	QUESTionable Status Register ..... 3-16
3.5.9.4	Multiple Logical Instruments ..... 3-18
3.5.10	Program Example ..... 3-19
3.6	CIIL Programming ..... 3-19

# TABLE OF CONTENTS

SECTION		PAGE
3.7	Calibration.....	3-19
3.8	Maintenance .....	3-19

## APPENDIX A - MS WINDOWS HELP FILES

A-1	Soft Front Panel.....	1
A.1.1	Soft Front Panel Overview .....	A-1
A.1.2	Soft Front Panel Controls.....	A-1
A.1.2.1	Init .....	A-1
A.1.2.2	Channel .....	A-1
A.1.2.3	Voltage .....	A-1
A.1.2.4	Current .....	A-1
A.1.2.5	Mode .....	A-1
A.1.2.6	Output .....	A-1
A.1.2.7	Polarity .....	A-1
A.1.2.8	Sys Reset.....	A-2
A.1.2.9	Chan Reset .....	A-2
A.1.2.10	Test .....	A-2
A-2	LabView Library.....	2
A.2.1	LabView Library Overview .....	A-2
A.2.1.1	Instr handle in.....	A-2
A.2.1.2	Instr handle out .....	A-2
A.2.1.3	Error in .....	A-2
A.2.1.4	Error out .....	A-2
A.2.2	LabView Library Functions.....	A-3
A.2.2.1	About.....	A-3
A.2.2.2	AutoCon .....	A-3
A.2.2.3	Chanl.....	A-3
A.2.2.4	Close .....	A-3
A.2.2.5	GetStatus .....	A-3
A.2.2.6	Initialize .....	A-4
A.2.2.7	Mode .....	A-4
A.2.2.8	Outp .....	A-4
A.2.2.9	Read.....	A-4
A.2.2.10	Reset.....	A-5
A.2.2.11	RevisionQuery.....	A-5
A.2.2.12	SelfTest .....	A-5
A.2.2.13	Set.....	A-5
A.2.2.14	Vers.....	A-6
A-6	Knowledge Base.....	6

## APPENDIX B - SCPI COMMON COMMAND/QUERY DEFINITIONS

B.1	Introduction.....	B-1
B.2	*CLS — Clear Status Command .....	B-1
B.3	*ESE — Standard Event Status Enable Command.....	B-1
B.4	*ESE? — Standard Event Status Enable Query.....	B-1
B.5	*ESR? — Event Status Register Query.....	B-2
B.6	*IDN? — Identification Query.....	B-2
B.7	*OPC — Operation Complete Command .....	B-2
B.8	*OPC? — Operation Complete Query .....	B-2
B.9	*OPT? — Options Query .....	B-3
B.10	*RST — Reset Command.....	B-3
B.11	*SRE — Service Request Enable Command .....	B-4
B.12	*SRE? — Service Request Enable Query .....	B-4
B.13	*STB? — Status Byte Register Query .....	B-4

# TABLE OF CONTENTS

SECTION	PAGE
B.14 *TRG — Trigger Command .....	B-4
B.15 *TST? — Self Test Query .....	B-4
B.16 *WAI — Wait-to-Continue Command .....	B-5

## APPENDIX C - SCPI COMMAND/QUERY DEFINITIONS

C.1 Introduction .....	C-1
C.2 INITiate[:IMMediate] Command .....	C-1
C.3 INITiate:CONTInuous Command .....	C-1
C.4 INITiate:CONTInuous Query .....	C-2
C.5 INSTRument:CATalog Query .....	C-2
C.6 INSTRument[:NSElect] Command .....	C-2
C.7 INSTRument[:SElect] Command .....	C-2
C.8 INSTRument[:SElect]? Query .....	C-3
C.9 INSTRument:STATe Command .....	C-3
C.10 MEASure[:SCALar]:CURRent[:DC]? Query .....	C-3
C.11 MEASure[:VOLTage][:SCALar][:DC]? Query .....	C-3
C.12 OUTPut[:STATe] Command .....	C-4
C.13 OUTPut[:STATe] Query .....	C-4
C.14 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPLitude] Command .....	C-4
C.15 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPLitude] Query .....	C-4
C.16 [SOURce:]CURRent[:LEVel]TRIGgered[:AMPLitude] Command .....	C-5
C.17 [SOURce:]CURRent[:LEVel]TRIGgered[:AMPLitude]? Query .....	C-5
C.18 [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPLitude] Command .....	C-6
C.19 [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPLitude]? Query .....	C-6
C.20 [SOURce:]VOLTage[:LEVel]TRIGgered[:AMPLitude] Command .....	C-6
C.21 [SOURce:]VOLTage[:LEVel]TRIGgered[:AMPLitude]? Query .....	C-6
C.22 [SOURce:]FUNctioN:MODE Command .....	C-7
C.23 STATus:OPERation:CONDition Query .....	C-7
C.24 STATus:OPERation:ENABle Command .....	C-7
C.25 STATus:OPERation:ENABle? Query .....	C-7
C.26 STATus:OPERation[:EVENT] Query .....	C-7
C.27 STATus:PRESet Command .....	C-8
C.28 STATus:QUESTionable[:EVENT]? Query .....	C-8
C.29 STATus:QUESTionable:CONDition? Query .....	C-9
C.30 STATus:QUESTionable:ENABle Command .....	C-9
C.31 STATus:QUESTionable:ENABle? Query .....	C-9
C.32 STATus:QUESTionable:INSTRument? Query .....	C-9
C.33 STATus:QUESTionable:INSTRument1? Query .....	C-10
C.34 STATus:QUESTionable:INSTRument2? Query .....	C-10
C.35 STATus:QUESTionable:INSTRument:ENABle Command .....	C-10
C.36 STATus:QUESTionable:INSTRument:ENABle Query .....	C-11
C.37 STATus:QUESTionable:INSTRument1:ENABle Command .....	C-11
C.38 STATus:QUESTionable:INSTRument1:ENABle? Query .....	C-11
C.39 STATus:QUESTionable:INSTRument2:ENABle Command .....	C-11
C.40 STATus:QUESTionable:INSTRument2:ENABle? Query .....	C-11
C.41 STATus:QUESTionable:INSTRument:ISUM Query .....	C-11
C.42 STATus:QUESTionable:INSTRument:ISUM:ENABle Command .....	C-11
C.43 STATus:QUESTionable:INSTRument:ISUM:ENABle? Query .....	C-12
C.44 SYSTem:ERRor[:NEXT]? Query .....	C-12
C.45 SYSTem:ERRor:CODE? Query .....	C-12
C.46 SYSTem:ERRor:CODE:ALL? Query .....	C-12
C.47 SYSTem:LANGuage Command .....	C-12
C.48 SYSTem:SET Command .....	C-13
C.49 SYSTem:VERSion Query .....	C-13

# TABLE OF CONTENTS

SECTION	PAGE
<b>APPENDIX D - CIIL COMMAND DEFINITIONS</b>	
D-1 Introduction .....	1
<b>APPENDIX E - GLOSSARY OF VXI TERMS</b>	
E-1 Introduction .....	1
<b>APPENDIX F - SAMPLE PROGRAM</b>	
F-1 Introduction .....	1
F-1 Description .....	1

# LIST OF FIGURES

FIGURE	TITLE	PAGE
1-1	Remotely Controlled Power Supply Configurations Using Kepco Products.....	viii
1-2	Typical Controller to Power Module Interface .....	1-3
1-3	Mechanical Outline Drawing .....	1-4
2-1	VXI Address Select.....	2-2
2-2	TMA VXI-27 Front Panel.....	2-3
3-1	TMA VXI-27 plug&play Directory Structure.....	3-3
3-2	TMA VXI-27 plug&play Controller Selection .....	3-3
3-3	TMA VXI-27 plug&play panel.....	3-4
3-4	Tree Diagram of SCPI Commands Used with TMA VXI-27 Controller .....	3-9
3-5	Message Structure.....	3-11
3-6	Status Reporting Structure.....	3-17
3-7	Expansion of QUEStionable Register for Multiple Logical Instruments .....	3-19
B-1	GPIB Commands .....	B-3
B-2	Using the *WAlT-to-continue Command .....	B-5
C-1	Use of INSTrument:CATalog Query .....	C-2
C-2	Identifying and Selecting Devices on BITBUS .....	C-3
C-3	Programming the Output.....	C-5
C-4	Programming Current .....	C-6
C-5	Using Status Commands and Queries.....	C-8
D-1	FNC — Function Command.....	D-1
D-2	INX — Initiate Op Code Command.....	D-2
D-3	FTH — Fetch Command.....	D-2
D-4	SET Command .....	D-3
D-5	OPN, CLS — Open, Close Relay Commands .....	D-4
D-6	RST — Reset Command .....	D-4
D-7	CNF, IST — Confidence Test, Internal Self Test Commands.....	D-4
D-8	STA — Status Command.....	D-5
D-9	GAL — Go to Alternate Language Command .....	D-6

# LIST OF TABLES

TABLE	TITLE	PAGE
1-1	Specifications .....	1-2
1-2	Accessories .....	1-3
2-1	Input/output Pin Assignments .....	2-3
3-1	Plug&play Panel Controls and Indicators .....	3-4
3-2	VXI Bus Commands .....	3-6
3-3	SCPI Command Index .....	3-10
3-4	Rules Governing Shortform Keywords .....	3-11
B-1	IEEE 488.2 Command/query Index .....	B-1
B-2	Standard Event Status Enable Register and Standard Event Status Register Bits .....	B-1
B-3	Service Request Enable and Status Byte Register Bits .....	B-4
C-1	SCPI Subsystem Command/query Index .....	C-1
C-2	Operation Condition Register, Operation Enable Register, and Operation Event Register Bits .....	C-7
C-3	Questionable Event Register, Questionable Condition Register and Questionable Condition Enable Register Bits .....	C-9
C-4	Questionable Instrument Register 0 Bits .....	C-10
C-5	Questionable Instrument Register 1 Bits .....	C-10
C-6	Questionable Instrument Register 2 Bits .....	C-10
C-7	Error Messages .....	C-13
D-1	CIIIL Subsystem Command/query Index .....	D-1
D-2	CIIIL Error Messages .....	D-5
D-3	CIIIL Error Handling Utility Commands .....	D-6




FIGURE 1-1. REMOTELY CONTROLLED POWER SUPPLY CONFIGURATIONS USING KEPSCO PRODUCTS

3040800

## SECTION 1 - INTRODUCTION

### 1.1 SCOPE OF MANUAL

This service manual contains the specifications and instructions for the installation and operation of the Model TMA VXI-27 Power Module Controller, manufactured by Kepco, Inc. Flushing, N.Y. U.S.A. A parts list and schematic diagrams are located in Section 4

### 1.2 GENERAL DESCRIPTION

The Kepco model TMA VXI-27 is a Power Module Controller which plugs into a VXI computer chassis and allows the user to program a VXI computer to control and monitor the outputs of up to 27 Kepco power modules (such as "MAT"s, "MBT"s, "MST"s and "BOP"s) equipped for communication via the IEEE 1118 two-wire serial bus (see Figure 1-1). The IEEE 1118 two-wire serial bus, also referred to as the Control Bus, allows the TMA VXI-27 to communicate with the 27 power modules up to a maximum distance of 1000 feet (300 meters).

The TMA VXI-27 includes *plug&play* software drivers which greatly simplify programming of the power supplies connected to the IEEE 1118 serial bus. This is accomplished through a "soft panel," a virtual panel that gives the operator access to power supply operating controls and indicators, allowing power supply operation by clicking a mouse on the virtual control, and observing power supply indicators and measured values on a computer monitor.

The TMA VXI-27 communicates with the VXI computer via the VXIbus (an abbreviation for "VMEbus eXtensions for Instrumentation") which is based on the worldwide VMEbus standard (IEEE STD 1014). The VXI backplane includes the 32-bit VME computer bus as well as high-performance instrumentation buses for precision timing and synchronization between instrument components. (See Appendix E for a Glossary of VXI terms.)

The TMA VXI-27 is a Message Based VXI servant interface with Programmable Interrupter capabilities for Event generation, conforming to Specification VXI-1, REV. 1.4. As a Message Based Device it implements all Word Serial Commands required for an I4 class (IEEE 488 compatible) Instrument (see Table 2-1). It is a Single Width C sized card.

The TMA VXI-27 communicates through the VXI backplane with the Resource Manager (Slot 0 Controller) using commands in either the default language, SCPI (Standard Commands for Programmable Instruments) commands (default), or CIIL (Control Interface Intermediate Language), the alternate language. The VXI Resource Manager, known as the Slot 0 Controller, is a common resource system module containing the VMEbus Resource Manager and VMEbus System Controller. The Resource Manager provides configuration management services, commander/servant mapping, self test and diagnostics.

The VXI Slot 0 Controller can set the output voltage with current limit, or the output current with voltage limit of any one of the 27 KEPCO Power Supplies interconnected through the Control Bus to the TMA VXI-27. It can then program the TMA VXI-27 to read back (through the Control Bus) the actual output voltage and current delivered by each of the power modules to their respective loads. The TMA VXI-27 continually polls all of the power modules on the Control Bus for error flags. All data transmissions between the Slot 0 Controller and the TMA VXI-27 are ASCII encoded. The values for the command parameters can be written in integer, decimal or scientific notation.

### 1.3 SPECIFICATIONS (SEE TABLE 1-1)

**TABLE 1-1. SPECIFICATIONS**


SPECIFICATION	DESCRIPTION
Device Type	Message-based
Device Substates	Initialize, Configure, Normal Operation
Applicable VXI Commands	See Table 3-2.
Addresses	Static, configurable between 1 and 254 using DIP switch (see PAR. 2.2.1).
Manufacturer ID	3804 <sub>10</sub> , (0EDC <sub>H</sub> ), read from register 0
Address Space	A16, normal handshake only
Programmable Interrupt	Generates Request True or Request False events
Interrupt Priority	Software assigned (via Slot 0 Controller) from 0 to 7; 0 = no interrupt (default), 1 = highest priority, 7 = lowest priority
Capabilities	Message-based Device with Word Serial Capabilities; VXIbus Instrument Protocol; I4 Class VXI Instrument
Input Power Requirement	Approximately 2A from +5V backplane of VXI.
Physical Dimensions	See Outline Drawing, Figure 1-3.

### 1.4 TMA VXI-27 INTERCONNECTIONS

A shielded two (2) wire twisted-pair cable equipped with a 9 pin D-type, male, plug-in connector (supplied) is used to connect the TMA VXI-27 with the power modules. Input power and input/output signals are provided through the VXI backplane (see Figure 1-2).

An opto-isolated, active high or non-isolated, active low, emergency shutdown input is provided on the 15 pin D-type female connector located on the front pane (see PAR. 3.1.2.1). On the same connector 2 additional lines provide a normally open contact indicating the proper functioning of the internal microsystem (Discrete Fault line). If either a serious malfunction or a catastrophic error occurs, the contacts will close (see PAR. 3.1.2.2)

In configurations where power modules are daisy chained on the IEEE 1118 control bus (see Figure 1-2), the last power module control bus outlet (in the daisy chain) must be terminated with the IEEE Control Bus Terminator supplied with the controller to reduce spurious noise and provide proper impedance matching. The terminator supplied is a 9-pin, D-type connector; for Kepco MAT Power Supplies with a round 5 pin connector use the 5 pin terminator listed in Table 1-2.



**FIGURE 1-2. TYPICAL CONTROLLER TO POWER MODULE INTERFACE**

**1.5 ACCESSORIES**

Table 1-2 lists the accessories for the TMA VXI-27 Controller.

**TABLE 1-2. ACCESSORIES**

ACCESSORY	PART NUMBER	USE	NOTE
Cable - two 9-pin connectors, ~ 6 ft. (2 m)	118-0844	Daisy chain TMA 4882-27and Kepco Power Supplies with 9-pin connector on IEEE 1118 bus.	Supplied
15 -Pin Connector	142-0276 (Amp P/N 205206-1)	Mating Connector for AUXILIARY SIGNALS connector	Supplied
Hood	108-0204 (Amphenol P/N 17-2588-6)	Used with 15-Pin Connector	Supplied
Snap-in	107-0187 (Amp P/N 66504-2)	Used with 15-Pin Connector	Supplied
Terminator, 9-pin	195-0086	Terminate IEEE 1118 bus daisy chain	Supplied
Terminator, 5-pin	195-0075	Terminate IEEE 1118 bus daisy chain (for MAT power supply with 5 pin round connector)	Not supplied
Cable - two 5-pin connectors	118-0699	Daisy chain Kepco Power Supplies with 5-pin connectors on IEEE 1118 bus.	Not supplied
Cable - one 5-pin and one 9-pin connector, ~6 ft. (2 m)	118-0749	Daisy chain TMA VXI-27 and Kepco Power Supplies with 5-pin connector on IEEE 1118 bus.	Not supplied
Cable - one 5-pin and one 9-pin connector, ~12 ft. (4 m)	118-0852	Daisy chain TMA VXI-27and Kepco Power Supplies with 5-pin connector on IEEE 1118 bus.	Not supplied
Cable - two 9-pin connectors, ~ 12 ft. (4 m)	118-0853	Daisy chain TMA VXI-27and Kepco Power Supplies with 9-pin connector on IEEE 1118 bus.	Not supplied




FIGURE 1-3. MECHANICAL OUTLINE DRAWING

C-3010116

## SECTION 2 - INSTALLATION

### 2.1 UNPACKING AND INSPECTION

The Model TMA VXI-27 has been carefully inspected and tested prior to packing. Inspect the shipping carton immediately upon receipt for evidence of damage during transit. Save the original packing material. If any indication of damage is found file a claim immediately with the responsible transport service.

For repairs of a product damaged in shipment, contact the Kepco Factory Representative nearest you or the Kepco Customer Service Department directly for further instruction.

### 2.2 INSTALLATION

The installation and setup procedure for the TMA VXI-27 consists of the following steps:

1. Set the VXI Address Selector (PAR. 2.2.1)
2. Select an empty slot in the C size VXI chassis and remove the slot cover plate.
3. Turn off the power if it is on and slide the TMA VXI-27 module into the chassis with the LEDs up (or to the left in the case of a horizontal chassis). Secure TMA VXI-27 to chassis with self-retaining screws at the top and bottom of the front panel
4. Connect the 9 pin D-type connector located on the front panel to the power modules through the Control Bus in a daisy chain configuration using the control bus cable supplied (see Figure 1-2). For installations that exceed the length of the control bus cable supplied, refer to Table 1-2 for cable specifications; the maximum cable length is 300 meters (1000 feet).
5. Connect Terminator (supplied) to last IEEE 1118 control bus connector in daisy chain (see Figure 1-2). (For Kepco MAT power supplies with 5-pin round connector, use terminator P/N 195-0075; see Table 1-2.)

NOTE: Terminator must be used even if only one power supply is connected to the Controller to ensure reduction of spurious noise and proper impedance matching.

6. To use the AUX. SIGNALS connector refer to PAR. 3.1.2 for a description of the available signals and PAR. 2.3 for connector type and pin assignments.
7. Connect all power module outputs to their respective loads.

#### 2.2.1 VXI ADDRESS SELECT

Set the VXI address selector to an unused VXI address between 1 and 254 using DIP switches accessible through the right shield as shown in Figure 2-1. The TMA VXI-27 address is preset to the factory default address of 6.

### 2.3 FRONT PANEL TERMINATIONS (SEE FIGURE 2-2.)

- a. IEEE 1118 (Control Bus) connector. Connections to the control bus are made through the IEEE 1118 connector, a 9 pin D-type female receptacle. Refer to Table 2-1 for pin assignments.

b. Auxiliary Signals connector. This is a 15 pin D-type female receptacle. Refer to Table 2-1 for pin assignments.

The DISCRETE FAULT LINE relay has the contacts open if the internal microsystem is functioning normal by monitoring a pulse generated in the timer interrupt routine. If the microsystem is not functioning normally or a catastrophic condition appears on one of the power modules the contacts will close and then reopen when the catastrophic condition disappears and the error buffer has been read (if the Command Language is CIIIL) or when the Device Dependent Error from the Event Status Register has been read (if the Command Language is SCPI).

The ISOLATED and NON ISOLATED EMERGENCY SHUT-DOWN INPUTS activates the non-maskable interrupt of the microsystem forcing the microsystem to send a reset to all KEPCO power supplies.





FIGURE 2-1. VXI ADDRESS SELECT

**TABLE 2-1. INPUT/OUTPUT PIN ASSIGNMENTS**

CONNECTOR	PIN	FUNCTION
IEEE 1118 (9-Pin, D-type, female)	1, 2, 6, 7	Ground
	3, 4, 5	IEEE 1118 (2-Wire Differential Interface)
	8, 9	IEEE 1118 (2-Wire Differential Interface)
AUX. SIGNALS (15-Pin, D-type, female)	1, 7, 8	Emergency Shut-down - Isolated Input Cathode (-)
	2, 5, 6	Emergency Shut-down - Isolated Input Anode (+)
	3, 4	+5v Output (Through 390 Ohm)
	9, 11	Ground
	10	Emergency Shut-down Input - Non Isolated
	12, 13	Discrete Fault Line - Relay Contact Pin 1
	14, 15	Discrete Fault Line - Relay Contact Pin 2



3040827

**FIGURE 2-2. TMA VXI-27 FRONT PANEL**



## SECTION 3 - OPERATION

### 3.1 LOCAL OPERATION

There is no local operation of the TMA VXI-27 controller; however, the controller provides three front panel LEDs (see PAR. 3.1.1) and three auxiliary functions (see PAR.3.1.2) to the user in addition to the remote programming capability described in PAR.'s 3.2 through 3.5.

#### 3.1.1 FRONT PANEL INDICATORS

The TMA VXI-27 is equipped with 3 front panel LEDs which have the following functions: (see Figure 2-2)

- a. **ONLINE.** The top LED (for vertically mounted unit), green colored, indicates that the power is applied and the internal microsystem is ON LINE. It is turned ON by an output port instruction executed by the internal microprocessor.
- b. **ACCESS.** The middle position LED, green colored, indicates that a VXI ACCESS cycle to address the module has been executed.
- c. **FAILED.** The bottom LED (for vertically mounted unit), red colored, indicates the FAILED condition. It is on during the power-up self test which is executed by the module every time the power is first applied or after a hardware reset. The VXI standard requires that this LED go off within 5 seconds. If this LED is still ON after 5 seconds, the VXI module is defective and has to be serviced.

#### 3.1.2 AUXILIARY SIGNALS

The AUX SIGNALS connector (see Table 2-1 and Figure 2-2) at the front panel provides the following auxiliary functions: emergency output shutdown, discrete fault, and +5V output.

##### 3.1.2.1 EMERGENCY OUTPUT SHUTDOWN

The emergency output shutdown function allows the user to reset all the power modules connected to the Control Bus with a single discrete signal. A user-initiated emergency shutdown activates the non-maskable interrupt of the microsystem, forcing the microsystem to send a reset to all power modules connected to the Control Bus. The NON-ISOLATED EMERGENCY SHUT-DOWN INPUT accepts a TTL input signal to initiate shutdown; this signal is referred to signal common. The ISOLATED EMERGENCY SHUT-DOWN INPUT requires a 2-wire isolated signal and return path.

##### 3.1.2.2 DISCRETE FAULT LINE

The DISCRETE FAULT LINE function provides a discrete controller fault indication by means of an internal relay. The DISCRETE FAULT LINE relay contacts are open (open circuit between DISCRETE FAULT LINE PIN 1 and PIN 2) if the internal microsystem is functioning normally; this is accomplished by monitoring a pulse generated in the timer interrupt routine. If the microsystem is not functioning normally, or a catastrophic condition appears on one of the power modules, the contacts will close. The contacts reopen when the catastrophic condition disappears *and* either the error buffer has been read (if the Command Language is CIIL) or when the Device Dependent Error from the Event Status Register has been read (if the Command Language is SCPI).

### 3.1.2.3 +5V OUTPUT

The +5V output is an auxiliary +5V source supplied through a 390 ohm resistor which can be used to power user-supplied external TTL circuits.

## 3.2 REMOTE OPERATION

The TMA VXI-27 Power Module Controller is programmed over the VXIbus using either SCPI (Standard Commands for Programmable Instruments) or CIIL (Control Interface Intermediate Language) commands. SCPI and CIIL provide a common language used in an automatic test system.

VXI plug&play drivers included with the TMA VXI-27 greatly simplify programming of power supplies connected to the controller via the IEEE 1118 serial bus (see PAR. 3.3). For detailed programming information, refer to PAR. 3.4 for VXIbus implementation, PAR. 3.5 for an explanation of SCPI programming, and PAR. 3.6 for CIIL programming.

## 3.3 VXI *plug&play* OPERATION

The TMA VXI-27 Controller includes two disks used to install VXI plug&play drivers. Once these drivers are installed, any of the power supplies connected to the TMA VXI-27 may be programmed directly; knowledge of the programming languages (SCPI and CIIL) and corresponding syntax is not required if the plug&play drivers are used.

### 3.3.1 BACKGROUND

The VXI plug&play Systems Alliance was formed in September, 1993 with the objective of increasing ease of use for end users of VXI technology. The Alliance endorsed and implemented additional common standards and practices in both hardware and software which exceeded the scope of the VXI Specifications. These standards are used to define system “frameworks” which give end users true “plug and play” interoperability at both the hardware and software levels. Of the three currently defined frameworks, DOS, WIN and GWIN, the TMA VXI-27 supports the GWIN (Graphical Windows) framework: an MS-DOS framework with key elements consisting of MS-Windows Soft Front Panel and LabView Drivers and documentation.

### 3.3.2 DRIVER INSTALLATION

The VXI plug&play install program uses the following structure: Drive C: is the default drive on MS-DOS based computers (this may be changed during installation). The root directory for all VXI plug&play drivers is VXIPNP. Each framework (DOS, WIN, and GWIN) is assigned a separate subdirectory and each instrument is assigned a subdirectory of the applicable framework; Figure 3-1 illustrates the directory structure for the TMA VXI-27 plug&play drivers.

- kptmavxi.exe — MS-Windows standalone executable file for TMA VXI-27 soft panel.
- kptmavxi.llb — LabView driver for soft panel.
- kptmavxi.hlp — MS-Windows help file (the MS Windows help files are also found in Appendix A).
- kptmavxi.kb — Knowledge base file which describes the TMA VXI-27.

To install the plug&play drivers, install floppy disk No. 1 in the appropriate drive and run SETUP.EXE, then follow directions as they appear on the screen.




FIGURE 3-1. TMA VXI-27 *plug&play* DIRECTORY STRUCTURE

### 3.3.3 OPERATING THE SOFT PANEL

To initiate operation of the soft panel, either choose this option after *plug&play* driver installation is complete, or double-click on the TMA VXI-27 icon in the VXIPNP program group available from Windows Program Manager, or run `kptmavxi.exe`.

The software will search for TMA VXI-27 controllers installed in the VXI mainframe. The first screen (shown below, Figure 3-2) lists the TMA VXI-27 Controller(s) installed, showing the associated slot and assigned logical address. Leave ID QUERY and RESET switches set to NO.

If only one controller is installed, click on the CONNECT button. If more than one controller is installed, click on a box at the left to select one controller. (Figure 3-2 shows two TMA VXI-27 controllers installed in slots 2 and 4 corresponding to logical addresses 7 and 6, respectively.)




FIGURE 3-2. TMA VXI-27 *plug&play* CONTROLLER SELECTION

The ID QUERY and RESET switches should be left in the NO position. (ID QUERY set to ON will send a verification of the type of instrument installed to the VXI Resource Manager. RESET set to ON will cause all power supplies to be reset to the initial power on condition when the controller is initialized.)

Once a controller has been selected, you will see the "virtual" panel of the Kepco power supply, (Figure 3-3). The slot selected is displayed in the SLOT window at the upper left corner of the panel. To operate the controls, click the mouse.




FIGURE 3-3. TMA VXI-27 *plug&play* PANEL

**3.3.3.1 UNDERSTANDING THE CONTROLS.** For on-line information about controls and indicators, click on SHOW HELP from the HELP menu. Then move the cursor over each control and indicator on the panel. Help text will appear and explain the function of each. Table 3-1 lists the function of each control and indicator.

TABLE 3-1. *Plug&play* PANEL CONTROLS AND INDICATORS

CONTROL/INDICATOR	FUNCTION	
MAX CHANNEL (switch)	Click on arrows to increase or decrease the number of channels to be scanned; set to correspond to the number of power supplies actually connected to the controller.	
SCAN SPEED (switch)	Click on arrows to select scan speed from fastest (10) to slowest (1).	
SCAN ON/OFF (switch)	Click to enables or disable polling of power supplies connected to the active controller.	
CHANNEL (switch)	Click on arrows to select channel. Power supply connected to selected channel (indicated by MODEL indicator) is visible on "virtual" panel.	
MODEL (indicator)	Indicates power supply model connected to selected channel.	
STATUS (indicators)	OPERATIONAL	Indicates value of status bits in operational register (see Figure B-17)
	QUESTIONABLE	Indicates value of status bits in questionable register (see Figure B-23)

**TABLE 3-1. Plug&play PANEL CONTROLS AND INDICATORS (CONTINUED)**

CONTROL/INDICATOR		FUNCTION
INIT (switch)		Click to select a different controller. If only one controller is installed, it will be automatically selected.
SYS RESET (switch)		Click to reset all power supplies connected to the selected controller (power supplies are reset to initial power-on condition)
CHAN RESET (switch)		Click to reset only the selected power supply (power supply is reset to initial power-on condition)
OUTPUT (switch)		Click to enable or disable the selected power supply output. (Operates relays on power supply models with relays; otherwise output voltage and current is set to zero.
POLARITY (switch)		Click to reverse polarity of power supply models incorporating polarity reversal feature.
MODE (switch)		Click to select Constant Voltage or Constant Current (alternate action).
TEST (switch)		Programs all power supplies connected to the controller to their maximum value, resets them, opens all relays (if present), then checks for errors in output. If error is detected, the channel number of the failed unit is selected, and the status values indicate the type of error detected.
MEASURED OUTPUT (indicators)	VOLTAGE meter	Provides analog and digital indication of measured voltage.
	CURRENT meter	Provides analog and digital indication of measured current
OUTPUT CONTROLS	VOLTAGE	Click on arrows to set voltage. If AUTOEXECUTE is set to ON, voltage value is immediately applied to power supply. If AUTOEXECUTE is set to OFF, voltage value is not applied to selected power supply until EXECUTE is clicked.
	CURRENT	Click on arrows to set current. If AUTOEXECUTE is set to ON, current value is immediately applied to power supply. If AUTOEXECUTE is set to OFF, current value is not applied to selected power supply until EXECUTE is clicked.
	EXECUTE (switch)	With AUTOEXECUTE set to OFF, click to apply VOLTAGE and CURRENT values to selected power supply.
	AUTOEXECUTE ON/OFF (switch)	Click to set ON/OFF (alternate action). When set to OFF, EXECUTE must be clicked to apply VOLTAGE and CURRENT values to selected power supply. When set to ON, VOLTAGE and CURRENT values are immediately applied to the selected power supply.
ACTIVE (indicator)		Lights (green) to indicate controller is active.
SLOT (indicator)		Displays slot of active controller
READ (indicator)		Lights (green) to indicate controller is reading information from power supply.
FAULT (indicator)		Lights (red) to indicate error detected. Error indicated by STATUS register values.
OUTPUT ON (indicator)		Lights (green) when power supply output is enabled.
REVERSED (indicator)		Lights (green) when power supply output polarity is reversed.
CV (indicator)		Lights (green) when power supply is in Constant Voltage mode. (If the Voltage Limit is exceeded while the power supply was programmed to be in Constant Current mode, the power supply will be forced into Constant Voltage mode (CV turns green) and the FAULT indicator lights (red).
CC (indicator)		Lights (green) when power supply is in Constant Current mode. (If the Current Limit is exceeded while the power supply was programmed to be in Constant Voltage mode, the power supply will be forced into Constant Current mode (CC turns green) and the FAULT indicator lights (red).

**TABLE 3-1. Plug&play PANEL CONTROLS AND INDICATORS (CONTINUED)**

CONTROL/INDICATOR	FUNCTION
ABOUT	Click for information about TMA VXI-27 plug&play driver.
CLOSE	Click to close plug&play soft panel. Closing the panel does not

**3.3.3.2 SELECT THE CHANNEL.** Click on the arrows on the CHANNEL box at the lower left. You will see the Kepco power supply Models connected to the system.

**3.3.3.3 SET THE VOLTAGE/CURRENT.** In the OUTPUT CONTROLS box at the lower center, click on the arrows to increase or decrease the voltage and current. If the power supply is set to Constant Voltage mode (CV indicator green), the CURRENT setting is the Current Limit. Similarly, if the power supply is set to Constant Current mode (CC green), the VOLTAGE setting is the voltage limit.

**3.3.3.4 APPLY PROGRAMMED SETTINGS TO THE POWER SUPPLY.** Click on EXECUTE. The programmed values for voltage and current limit are now applied to the selected power supply. If AUTOEXECUTE is clicked to ON, the VOLTAGE and CURRENT settings will be immediately applied to the selected power supply.

**3.3.3.5 ENABLE THE POWER SUPPLY OUTPUT.** Click on the OUTPUT button to the left of the meters to enable the output. The OUTPUT ON indicator turns green. The measured values of voltage and current are indicated by the VOLTAGE and CURRENT meters. Note that the meters give both a digital and analog representation of voltage and current.

### 3.4 VXIBUS COMMUNICATION

Table 3-2 defines the VXI commands implemented in the TMA VXI-27 in accordance with Specification VXI-1, Rev. 1.4 for a class I4 instrument.

**TABLE 3-2. VXI BUS COMMANDS**

VXI Command	Description	TMA VXI-27 Responds if active substate is:	
		Configure	Normal Operation
ABORT NORMAL OPERATION	Causes the TMA VXI-27 to cease normal operation and return to its default configuration (the same configuration occurring after hardware reset at power up) with interrupt unasserted.	YES	NO
ASSIGN INTERRUPTER LINE	Used to assign a VXibus IRQ line to the TMA VXI-27 module interrupter. The default value is 0 which means NO INTERRUPTS.	YES	NO
ASYNCHRONOUS MODE CONTROL	Used to direct the path of events and responses and also enable or disable the generation of events and responses. The TMA VXI-27 supports only EVENTS as INTERRUPTS; any other combination will generate an error	YES	NO
BEGIN NORMAL OPERATION (With or without TOP LEVEL bit)	Notifies the TMA VXI-27 that it can begin normal operation. In response, the TMA VXI-27 sets the corresponding flags in order to be ready to receive commands through the WORD SERIAL PROTOCOL. The TOP LEVEL bit (bit 8) is used to identify the device as a Top Level Commander.	YES	NO

**TABLE 3-2. VXI BUS COMMANDS (CONTINUED)**

VXI Command	Description	TMA VXI-27 Responds if active substate is:	
		Configure	Normal Operation
BYTE AVAILABLE	Sends SCPI or CIL commands to the TMA VXI-27. Also used to send IEEE 488.2 common commands.	NO	YES
BYTE AVAILABLE + END	Same as BYTE AVAILABLE except that bit 8 (END) is set to identify the byte as the last byte of the message.	NO	YES
BYTE REQUEST	Reads responses from commands previously sent to the TMA VXI-27.	NO	YES
CLEAR	Causes the TMA VXI-27 to clear its internal buffers and reset the VXI error.	YES	NO
CONTROL EVENT	<p>Causes the TMA VXI-27 to selectively enable or disable the generation of a specific event. The TMA VXI-27 can generate two events, REQUEST TRUE and REQUEST FALSE. After power up, these events are both enabled (in accordance with the VXI Specification).</p> <p>The REQUEST TRUE event is sent when the TMA VXI-27 requires service from its commander (the SERVICE REQUEST bit from the status byte goes TRUE and the EVENTS AS INTERRUPT and REQUEST TRUE FLAG are enabled).</p> <p>The REQUEST FALSE event is sent by the TMA VXI-27 when it no longer requires service from its commander (the SERVICE REQUEST bit from the status byte goes FALSE and the EVENTS AS INTERRUPT and REQUEST FALSE FLAG are enabled).</p>	YES	NO
CONTROL RESPONSE	Implemented; however, since the TMA VXI-27 does not generate response signals or response interrupts, any attempt to enable responses will generate an error.	YES	NO
END NORMAL OPERATION	Causes the TMA VXI-27 to end the normal operation and to go back to the CONFIGURE sub-state. This command will report an error (7 in the STATUS FIELD) if the device was already in the configure state when the command was issued.	YES	NO
READ INTERRUPTER LINE	Used to determine the VXIbus IRQ line assigned to the TMA VXI-27 interrupter. The default value is 0 which means NO INTERRUPTS.	YES	NO
READ INTERRUPTERS	Used to determine the number of interrupters within a SERVANT device. The TMA VXI-27 has only one interrupter, therefore 1 will be returned in the answer word. This result will be used in the next command (READ INTERRUPTER LINE) in which the commander can interrogate the TMA VXI-27 to determine which IRQ line is connected to this interrupter.	YES	NO
READ PROTOCOL	Used to determine what protocols, in addition to the Word Serial Protocol, the TMA VXI-27 supports. This is usually the first command sent by the Resource Manager after power up and determines all subsequent commands issued to the device. The TMA VXI-27 response to this command is 8623 Hex which means that it is capable of Event Generation, that it has a Programmable Interrupter (which means it supports the Read Interrupters, Read Interrupter Line, and Assign Interrupter Line commands), that it supports Word Serial TRIGGER command and that it also supports the VXIbus Instrument Protocol as an I4 class Instrument.	YES	NO

**TABLE 3-2. VXI BUS COMMANDS (CONTINUED)**

VXI Command	Description	TMA VXI-27 Responds if active substate is:	
		Configure	Normal Operation
READ PROTOCOL ERROR	Issued by the COMMANDER to interrogate the TMA VXI-27 about the cause of its current error (the TMA VXI-27 has activated the Err bit in the Response register). The errors which can be reported by the TMA VXI-27 are the following: Multiple Queries, Unsupported Command, DIR Violation, DOR Violation, Write Ready Violation.	YES	NO
READ STB	Used to read the status word from the TMA VXI-27. Because the TMA VXI-27 is a class I4 Instrument (implementing the IEEE 488.2 common commands), the value returned is the same as the value read by executing *STB?.	NO	YES
<p>NOTE: It is more advantageous to execute the VXIbus Word Serial Protocol READ STB command than the *STB? because it is faster (only one VXI cycle) and more accurate than *STB?. It is more accurate because STB? is a query (which asks for Word Serial Read; BYTE REQUEST command is the reply) which will always have the Message Available bit reset (because taking the reply empties the output queue). Instead, the VXI READ STB shows the exact status of the output queue (it does not use the output queue for the reply).</p>			

### 3.4.1 TYPICAL VXIBUS START-UP SEQUENCE

The following is a typical sequence of commands which are sent to the TMA VXI-27 by the resource manager upon power up:

1. The first command is READ PROTOCOL; the TMA VXI-27 replies with 8623 Hex (as described in Table 3-2 above).
2. the next command is READ INTERRUPTERS to determine the IRQ line assigned to the TMA VXI-27 interrupter.
3. This is followed by ASSIGN INTERRUPTER LINE which connects the TMA VXI-27 interrupter to an active IRQ line (between 1 and 7) if the resource manager wants events sent as interrupts. This can be followed by READ INTERRUPTER LINE if the resource manager wants to verify that the interrupter is connected to the requested IRQ line.
4. After configuration commands described above, it is expected that the resource manager will issue the BEGIN NORMAL OPERATION COMMAND followed by \*idn? (SCPI command) to identify the TMA VXI-27.
5. The power modules connected to the TMA VXI-27 can now be programmed using either SCPI (PAR. 3.5) or CILL (PAR. 3.6) commands sent as Word Serial Protocol Messages.

### 3.5 SCPI PROGRAMMING

SCPI (Standard Commands for Programmable Instruments) is a programming language conforming to the protocols and standards established by IEEE 488.2 (reference document *ANSI/IEEE Std 488.2, IEEE Standard Codes, Formats, Protocols, and Common Commands*). SCPI commands are sent to the TMA VXI-27 controller as output strings within the selected programming language (PASCAL, BASIC, etc.) in accordance with the VXIbus command protocol (PAR. 3.4).

#### 3.5.1 SCPI MESSAGES

There are two kinds of SCPI messages: program messages from controller to power supply, and response messages from the power supply to the controller. Program messages consist of one or more properly formatted commands/queries and instruct the power supply to perform an

action; the controller may send a program message at any time. Response messages consist of formatted data; the data can contain information regarding operating parameters, power supply state, status, or error conditions.

### 3.5.2 COMMON COMMANDS/QUERIES

Common commands and queries are defined by the IEEE 488.2 standard to perform overall power supply functions (such as identification, status, or synchronization) unrelated to specific power supply operation (such as setting voltage/current). Common commands and queries are preceded by an asterisk (\*) and are defined and explained in APPENDIX A (see Table 3-3). Refer also to syntax considerations (PAR.s 3.5.3 through 3.5.8).

### 3.5.3 SCPI SUBSYSTEM COMMAND/QUERY STRUCTURE

Subsystem commands/queries are related to specific power supply functions (such as setting output voltage, current limit, etc.) Figure 3-4 is a tree diagram illustrating the structure of SCPI subsystem commands used in the TMA VXI-27 with the “root” at the left side, and specific commands forming the branches. The subsystem commands are defined and explained in Appendix B (see Table 3-3).




FIGURE 3-4. TREE DIAGRAM OF SCPI COMMANDS USED WITH TMA VXI-27 CONTROLLER


**TABLE 3-3. SCPI COMMAND INDEX**

COMMAND	PAR. REFERENCE	COMMAND	PAR. REFERENCE	COMMAND	PAR. REFERENCE
*CLS	B.2	INST:STAT	C.9	STAT:QUES?	C.28
*ESE	B.3	MEAS:CURR?	C.10	STAT:QUES:COND?	C.29
*ESE?	B.4	MEAS:VOLT?	C.11	STAT:QUES:ENAB	C.30
*ESR?	B.5	OUTP:[STAT]	C.12	STAT:QUES:ENAB?	C.31
*IDN?	B.6	OUTP:[STAT]?	C.13	STAT:QUES:INST?	C.32
*OPC, *OPC?	B.7, B.8	[SOUR]:CURR	C.14	STAT:QUES:INST1?	C.33
OPT?	B.9	[SOUR]:CURR?	C.15	STAT:QUES:INST2?	C.34
*RST	B.10	[SOUR]:CURR:TRIG	C.16	STAT:QUES:INST:ENAB, ?	C.35, C.36
*SRE	B.11	[SOUR]:CURR:TRIG?	C.17	STAT:QUES:INST1:ENAB, ?	C.37, C.38
*SRE?	B.12	[SOUR]:VOLT	C.18	STAT:QUES:INST2:ENAB, ?	C.39, C.40
*STB?	B.13	[SOUR]:VOLT?	C.19	STAT:QUES:INST:ISUM?	C.41
*TRG	B.14	[SOUR]:VOLT:TRIG	C.20	STAT:QUES:INST:ISUM:ENAB, ?	C.42, C.43
*TST	B.15	[SOUR]:VOLT:TRIG?	C.21	SYST:ERR	C.44
*WAI	B.16	[SOUR]:FUNC:MODE	C.22	SYST:ERR:CODE?	C.45
INIT:[IMM]	C.2	STAT:OPER:COND?	C.23	SYST:ERR:CODE:ALL?	C.46
INIT:CONT	C.3	STAT:OPER:ENAB	C.24	SYST:LANG	C.47
INIT:CONT?	C.4	STAT:OPER:ENAB?	C.25	SYST:SET	C.48
INST:CAT	C.5	STAT:OPER?	C.26	SYST:VERS?	C.49
INST, INST?	C.6, C.7, C.8	STAT:PRES	C.27		

### 3.5.4 PROGRAM MESSAGE STRUCTURE

SCPI program messages (commands from controller to power supply) consist of one or more *message units* ending in a *message terminator*. The message terminator is not part of the syntax; it is defined by the way your programming language indicates the end of a line (such as a “new-line” or “end-of-line” character). The message unit is a keyword consisting of a single command or query word followed by a message terminator (e.g., CURR?<newline> or TRIG<end-of-line>). The message unit may include a data parameter after the keyword separated by a space; the parameter is usually numeric (e.g., CURR 5<newline>), but may also be a string (e.g., OUTP ON<newline>). Figure 3-5 illustrates the message structure, showing how message units are combined. The following subparagraphs explain each component of the message structure.

NOTE: An alternative to using the message structure for multiple messages defined in the following paragraphs is to send each command as a separate line. In this case each command must use the full syntax shown in Appendix B.



**FIGURE 3-5. MESSAGE STRUCTURE**

**3.5.4.1 KEYWORD**

Keywords are instructions recognized by a decoder within the TMA VXI-27, referred to as a “parser.” Each keyword describes a command function; all keywords used by the TMA VXI-27 are listed in Figure 3-4.

Each keyword has a long form and a short form. For the long form the word is spelled out completely (e.g., STATUS, OUTPUT, VOLTAGE, and TRIGGER are long form keywords). For the short form only the first three or four letters of the long form are used (e.g., STAT, VOLT, OUTP, and TRIG). The rules governing short form keywords are presented in Table 3-4.

**TABLE 3-4. RULES GOVERNING SHORTFORM KEYWORDS**

IF NUMBER OF LETTERS IN LONGFORM KEYWORD IS:	AND FOURTH LETTER IS A VOWEL?	THEN SHORT FORM CONSISTS OF:	EXAMPLES
4 OR FEWER	(DOES NOT MATTER)	ALL LONG FORM LETTERS	MODE
5 OR MORE	NO	THE FIRST FOUR LONG FORM LETTERS	MEASure, OUTPut, EVENT
5 OR MORE	YES	THE FIRST THREE LONG FORM LETTERS	LEVel, IMMEDIATE, ERRor

You must use the rules above when using keywords. Using an arbitrary short form such as ENABL for ENAB (ENABLE) or IMME for IMM (IMMEDIATE) will result in an error. Regardless of which form chosen, you must include all the letters required by that form.

To identify the short form and long form in this manual, keywords are written in upper case letters to represent the short form, followed by lower case letters indicating the long form (e.g., IMMEDIATE, EVENT, and OUTPUT). The parser, however, is not sensitive to case (e.g., outp, OutP, OUTPUT, ouTPut, or OUTp are all valid).

#### **3.5.4.2 KEYWORD SEPARATOR**

If a command has two or more keywords, adjacent keywords must be separated by a colon (:) which acts as the keyword separator (e.g., CURR:LEV:TRIG). The colon can also act as a root specifier (PAR. 3.5.4.7).

#### **3.5.4.3 QUERY INDICATOR**

The question mark (?) following a keyword is a query indicator. This changes the command into a query. If there is more than one keyword in the command, the query indicator follows the last keyword. (e.g., VOLT? and MEAS:CURR?).

#### **3.5.4.4 DATA**

Some commands require data to accompany the keyword either in the form of a numeric value or character string. Data always follows the last keyword of a command or query (e.g., VOLT:LEV:TRIG 14 or SOUR:VOLT? MAX

#### **3.5.4.5 DATA SEPARATOR**

Data must be separated from the last keyword by a space (e.g., VOLT:LEV:TRIG 14 or SOUR:VOLT? MAX

#### **3.5.4.6 MESSAGE UNIT SEPARATOR**

When two or more message units are combined in a program message, they must be separated by a semicolon (;) (e.g., VOLT 15;MEAS:VOLT? and CURR 12; CURR:TRIG 12.5).

#### **3.5.4.7 ROOT SPECIFIER**

The root specifier is a colon (:) that precedes the first keyword of a program message. This places the parser at the root (top left, Figure 3-4) of the command tree. Note the difference between using the colon as a keyword separator and a root specifier in the following examples:

VOLT:LEV:IMM 16 Both colons are keyword separators.

:CURR:LEV:IMM 4 The first colon is the root specifier, the other two are keyword separators.

VOLT:LEV 6;;CURR:LEV 15 The second colon is the root specifier, the first and third are keyword separators

:INIT ON;;TRIG;;MEAS:CURR?;VOLT? The first three colons are root specifiers.

### 3.5.4.8 MESSAGE TERMINATOR

The message terminator defines the end of a message. Three message terminators are permitted:

- new line (<NL>), ASCII 10 (decimal) or 0A (hex)
- (<CR>), ASCII 13 (decimal) or 0D (hex)
- both of the above (<CR> <NL>)

Your GPIB interface card software will automatically send a message terminator. For example, the HP BASIC OUTPUT statement inserts <NL> after the last data byte. When binary data is exchanged, <END> must be used. The combination <NL><END> terminator can be used for all data except binary data.

NOTE: Kepeco power modules *require* a message terminator at the end of each program message. The examples shown in this manual assume a message terminator will be added at the end of each message. Where a message terminator is shown it is represented as <NL> regardless of the actual terminator character.

### 3.5.5 UNDERSTANDING THE COMMAND STRUCTURE

Understanding the command structure requires an understanding of the subsystem command tree illustrated in Figure 3-4. The “root” is located at the top left corner of the diagram. The parser goes to the root if:

- a message terminator is recognized by the parser
- a root specifier is recognized by the parser

*Optional keywords* are enclosed in brackets [ ] for identification; optional keywords can be omitted and the power supply will respond as if they were included in the message. The root level keyword [SOURCE] is an optional keyword. Starting at the root, there are various branches or paths corresponding to the subsystems. The root keywords for the TMA VXI-27 are :INITiate, :MEASure, :OUTPut, [:SOURCE], :STATus, and :SYSTem. Because the [SOURCE] keyword is optional, the parser moves the path to the next level, so that VOLTage, CURRent, and FUNCtion commands are at the root level.

Each time the parser encounters a keyword separator, the parser moves to the next indented level of the tree diagram. As an example, the STATus branch is a root level branch that has three sub-branches: OPERation, PRESet, and QUEStionable. The following illustrates how SCPI code is interpreted by the parser:

**STAT:PRES<NL>**

The parser returns to the root due to the message terminator.

**STAT:OPER?;PRES<NL>**

The parser moves one level in from STAT. The next command is expected at the level defined by the colon in front of OPER?. Thus you can combine the following message units STAT:OPER? and STAT:PRES;

**STAT:OPER:COND?;ENAB 16<NL>**

After the OPER:COND? message unit, the parser moves in one level from OPER, allowing the abbreviated notation for STAT:OPER:ENAB.

### 3.5.6 ADDRESSING MULTIPLE POWER SUPPLIES

Power supplies on the IEEE 1118 bus are selected by node address, also referred to as node number or channel number. Refer to the applicable manuals for the power modules connected to the IEEE 1118 bus to set each power module to a unique node number, from 1 to 31 (a maximum of 27 power modules may be connected to the bus).

The node number may follow any part of a SCPI command. Note that there must be no space preceding the node number

e.g., `meas2:volt?` or `meas:volt2?` both measure output voltage of the power supply at node number 2.

e.g., `func3:mode volt` or `func:mode3 volt` both set the power supply at node number 3 to commanded voltage mode.

e.g., `stat1:ques?` or `stat:ques1?` or `stat:ques:cond1?` all read Questionable Register status of the power supply at node number 1.

Upon power turn-on, commands sent without a node (channel) number will go to the default node address (1) until another node number is specified. Once another node number is specified, the new number becomes the default until another is specified.

NOTE: The node selected can also be changed using the `INSTRument:SElect <N>` command. This allows subsequent commands to operate on the specified node (e.g. `INST:SEL 10` causes node 10 to be selected).

### 3.5.7 UNDERSTANDING THE COMMAND STRUCTURE

Understanding the command structure requires an understanding of the subsystem command tree illustrated in Figure 3-4. The “root” is located at the top left corner of the diagram. The parser goes to the root if:

- a message terminator is recognized by the parser
- a root specifier is recognized by the parser

*Optional keywords* are enclosed in brackets [ ] for identification; optional keywords can be omitted and the power supply will respond as if they were included in the message. The root level keyword `[SOURce]` is an optional keyword. Starting at the root, there are various branches or paths corresponding to the subsystems. The root keywords for the TMA VXI-27 controller are `:INITiate`, `:MEASure`, `:OUTPut`, `[:SOURce]`, `:STATus`, and `:SYSTem`. Because the `[SOURce]` keyword is optional, the parser moves the path to the next level, so that `VOLTage`, `CURRent`, and `FUNCTion` commands are at the root level.

Each time the parser encounters a keyword separator, the parser moves to the next indented level of the tree diagram. As an example, the `STATus` branch is a root level branch that has three sub-branches: `OPERation`, `PRESet`, and `QUESTionable`. The following illustrates how SCPI code is interpreted by the parser:

**STAT:PRES<NL>**

The parser returns to the root due to the message terminator.

**STAT:OPER?;PRES<NL>**

The parser moves one level in from `STAT`. The next command is expected at the level defined

by the colon in front of OPER?. Thus you can combine the following message units STAT:OPER? and STAT:PRES;

**STAT:OPER:COND?;ENAB 16<NL>**

After the OPER:COND? message unit, the parser moves in one level from OPER, allowing the abbreviated notation for STAT:OPER:ENAB.

### 3.5.8 PROGRAM MESSAGE SYNTAX SUMMARY

- Common commands begin with an asterisk (\*).
- Queries end with a question mark (?).
- Program messages consist of a root keyword and, in some cases, one or more message units separated by a colon (:) followed by a message terminator. Several message units of a program message may be separated by a semicolon (;) without repeating the root keyword.
- If a program message has more than one message unit, then a colon (:) must precede the next keyword in order to set the parser back to the root (otherwise the next keyword will be taken as a subunit of the previous message unit).

e.g., the command `meas:volt?;curr?` will read output voltage and output current since both `volt?` and `curr?` are interpreted as subunits of the `meas` command.

- Several commands may be sent as one message; a line feed terminates the message. Commands sent together are separated by a semicolon (;). The first command in a message starts at the root, therefore a colon (:) at the beginning is not mandatory.

e.g., the command `meas:volt?;:curr?` will read output voltage and programmed current since the colon preceding `curr?` indicates that `curr?` is not part of the `meas` command and starts at the root.

- UPPER case letters in mnemonics are mandatory (short form). Lower case letters may either be omitted, or must be specified completely (long form)  
e.g., **INST** (short form) has the same effect as **INSTRUMENT** (long form).
- Commands/queries may be given in upper/lower case (long form)  
e.g., **SoUrCe** is allowed.
- Text shown between brackets [] is optional.  
e.g., **:[SOUR]VOLT:[LEV] TRIG** has the same effect as **:VOLT TRIG**

### 3.5.9 STATUS REPORTING

The status reporting of the TMA VXI-27 follows the SCPI and IEEE 488.2 requirements. The serial poll response of the TMA VXI-27 provides summary bits of the status and error reporting system. The simplest status report is the command valid reporting and data availability. This successful decoding of a command string generates no error and is indicated by the bit 3 of the serial poll response being a zero. The setting of bit 4 in the status byte indicates data is available to the controller in response a command query message.

### 3.5.9.1 STATUS REPORTING STRUCTURE

The status reporting of the TMA VXI-27 uses four status registers, illustrated in Figure 3-6. These registers are the Questionable, Operation, Standard Event and Service Request registers. The Questionable and Operation registers are 16 bit registers and the Standard Event and Service Request registers are 8 bits. These four registers are referred to as condition registers. Each of the four condition registers is associated with two related registers: an event register which holds unlatched events reported in realtime by the instrument and is cleared by reading the register, and an enable register which allows the contents of the event register to be passed through to set the associated condition register.

A zero to one transition of a condition register is added to the event register if the specific bit in the enable register is also a 1. Reading an event register clears all of the bits found in the event register. If any bits are set in an event register, the following condition register bit is then set. For example, if the STAT:QUES:ENB (enable) register has bit 0 set and a voltage error is detected, the event registers bit 0 is set. The 1 in the event register causes bit 3 of the status byte to be asserted. The Service Request register is ANDed with its enable register for all bits except bit 6. The result is placed in bit 6 of the Service Request register. If bit 6 is a 1 (true), it causes the TMA VXI-27 to assert the SRQ line to the host controller.

Figure 3-6 also shows that if the error/event queue is not empty, bit 3 is set in the Service Request register and bit 4 indicates that a message is available in the output buffer.

### 3.5.9.2 OPERATIONAL STATUS REGISTER

The OPERational condition register contains conditions which are a part of the instrument's normal operation. The definition of each of these bits (condition register) is as follows:

- 1 through 7 - Not Used — always zero.
- 8 - Constant Voltage — 1 indicates the instrument is in constant voltage mode.
- 9 - Relay — 1 indicates the power supply output relay is closed.
- 10 - Constant Current — 1 indicates the instrument is in constant current mode.
- 11 through 15 - Not Used — always zero.

### 3.5.9.3 QUESTIONABLE STATUS REGISTER


The QUEStionable condition register (see Figure 3-6) contains status bits representing data/signals which give an indication of the quality of various aspects of the signal.

A bit set in the QUEStionable condition register indicates that the data currently being acquired or generated is of questionable quality due to some condition affecting the parameter associated with that bit.

- 8 - Voltage Mode — 1 indicates the instrument is in Voltage mode.
- 9 - Relay — 1 indicates the power supply output relay is closed, unit is supplying power at output terminals.
- 10 - Current Mode — 1 indicates the Power Supply is in Current mode. Changes in this bit do not affect the event register.
- 14 - Command warning — This bit indicates a non-fatal warning that relates to the instrument's interpretation of a command, query, or on or more parameters of a specific

command or query. The power supply sets this bit for

- MEAS:VOLT? 10,1 — The 10 is the number of digits and the 1 is the range. Since this capability is not implemented in Kepco power supplies, the Command Warning bit is set.
- INST:SEL 2 sent to a single power supply. Trying to select unit 2 when only one power supply is connected causes the Command Warning bit to be set.



3041682

**FIGURE 3-6. STATUS REPORTING STRUCTURE**

### 3.5.9.4 MULTIPLE LOGICAL INSTRUMENTS


The TMA VXI-27 is a SCPI device that supports multiple logical instruments; it allows a choice between two methods of status reporting. The status reporting default upon powerup treats the unit as a single channel instrument. When multiple channels are in use, a SCPI compliant status structure can be selected which provides an INSTRUMENT summary status register and an individual instrument ISUMmary for each logical instrument. These registers are equivalent to the Status Questionable register of a single channel instrument and are also found in the STATUS Questionable register for the selected channel. The contents of the STATUS Questionable register can also contain the summary of all instruments as shown in Figure 3-7.

The selection of the status reporting structure is controlled by the `SYSTEM:SET SI` (Instrument Structure) command, either `SI0` (off) or `SI1` (on). The power-up default is the off condition. To enable the SCPI compliant mode of operation for multiple logical instruments the user must send `SYSTEM:SET SI1` to the TMA VXI-27 power supply during initialization. The `SI1` state is not remembered when the unit is turned off. To return to the standard method of reporting the selected device's status without turning the unit off, send `SYSTEM:SET SI0`.

When the TMA VXI-27 power supply is set up for SCPI compliant status reporting for multiple channels, the specific instrument's Questionable register is found in the `STAT:QUES:INST:ISUM<n>` register. This register has the same bit structure as the single channel Questionable register. The ISUM enable register is ANDed with the bits of the channel's ISUM register and its bit is placed in the INST register. The Questionable register bits are the logical ORing of all channels' Questionable ISUM register. This is shown in figure 3-7.

The ISUMmary registers set the INSTRUMENT register, which in turn sets bit 13 of the QUESTIONABLE or OPERATION status register. This is shown pictorially in Figure 3-7.

The `STATUS:QUESTIONABLE` and `STATUS:QUESTIONABLE:CONDITION` registers are the same in this mode of status reporting. The condition register indicates the status of the various event registers and bits set are only cleared if the source of the bit is cleared.



**FIGURE 3-7. EXPANSION OF QUESTIONABLE REGISTER FOR MULTIPLE LOGICAL INSTRUMENTS**

### 3.5.10 PROGRAM EXAMPLE

Appendix F is a sample program illustrating communication with the TMA VXI-27. The sample program is written in C language for a National Instruments embedded slot 0 controller using LabWindows. Although the program is for a specific manufacturer's hardware, the techniques for other manufacturers are similar.

The program illustrates:

- how to communicate to the register level
- how to use the Word Serial Protocol
- how to use the interrupt capabilities of the TMA VXI-27, even though they are not used in the LABVIEW library.

### 3.6 CIIL PROGRAMMING

The CIIL command language is used on early models of Kepco power supplies and controllers. The command functions are included here for compatibility with other equipment programmed with CIIL commands. The CIIL command set for the TMA VXI-27 Controller is defined and explained in Appendix D.

### 3.7 CALIBRATION

The TMA 4882-27 requires no calibration.

### 3.8 MAINTENANCE

No preventive or scheduled maintenance is required.



## APPENDIX A - MS WINDOWS HELP FILES

### A.1 SOFT FRONT PANEL

#### A.1.1 SOFT FRONT PANEL OVERVIEW

The soft front panel may be executed by clicking on the icon in the VXIPNP group or by running 'kptmaxxi.exe'. It provides a means of checking out your Kepco power supply system as soon as you plug in the TMA VXI-27 controller and connect your Kepco power supplies to it.

#### A.1.2 SOFT FRONT PANEL CONTROLS

##### A.1.2.1 Init

The Init control allows selection of a Kepco TMA VXI-27 power supply controller, if more than 1 controller is present. If only one is present it will automatically be selected. If no controllers are present a message will appear and the function should be canceled.

##### A.1.2.2 Channel

The Channel control is used to select the power supply to which subsequent commands shall be applied.

##### A.1.2.3 Voltage

The Voltage control is used to set the value of output voltage to which the power supply shall be programmed. If AutoExecute is set to the ON position, the command is issued immediately, otherwise the execute button must be pressed to apply the new value.

##### A.1.2.4 Current

The Current control is used to set the value of output current to which the power supply shall be programmed. If AutoExecute is set to the ON position, the command is issued immediately, otherwise the execute button must be pressed to apply the new value.

##### A.1.2.5 Mode

The Mode control selects which mode of operation, constant voltage or constant current, the power supply should operate in. If the selected mode is not possible, because of the load value, an overload status error will be set in the questionable status register.

##### A.1.2.6 Output

The Output control is used to enable or disable the output of the power supply, via the output relay, on models which have relays.

##### A.1.2.7 Polarity

The Polarity control is used to select the output polarity, positive or negative, of the power supply, on units which have output relays.

### **A.1.2.8 Sys Reset**

The Sys Reset control causes all power supplies connected to the TMA VXI-27 controller to reset to their power on state.

### **A.1.2.9 Chan Reset**

The Chan Reset control causes the selected channel to reset to its power on state.

### **A.1.2.10 Test**

The Test control programs all power supplies to their maximum output values, then resets them, opens all relays, if present, and checks for errors in output. If any errors are present the channel numbers of the failed units are returned, otherwise a 0 is returned.

## **A.2 LABVIEW LIBRARY**

### **A.2.1 LABVIEW LIBRARY OVERVIEW**

The LabView Library provides functions to be used under National Instruments LabView 5.0 control software package for windows. The functions provide a means of controlling Kepco power supplies.

Most functions contain the following parameters in addition to any function specific parameters:

- Instrument handle In
- Instrument handle out
- Error in
- Error out

#### **A.2.1.1 Instr handle in**

This is a unique instrument identifier, which is required by most functions. Its value is obtained from the AutoCon or Initialize function, at the Instr handle out terminal

#### **A.2.1.2 Instr handle out**

This is a unique instrument identifier returned by the initialize or AutoCon function, and is used by other functions as the Instr handle in

#### **A.2.1.3 Error in**


This is the input error cluster, which passes error information to a function. It is usually wired to the error out terminal of a preceding function.

#### **A.2.1.4 Error out**

This is the output error cluster, which passes error information after a function call. It can be used to pass the information from a function to the error in terminal of the next function called.

## A.2.2 LABVIEW LIBRARY FUNCTIONS

### A.2.2.1 About



**KPTMAVXI About.vi**

The About function returns information about the software and firmware, including the revision number of each.


### A.2.2.2 AutoCon



**KPTMAVXI AutoCon.VI**

The AutoCon function searches the VXI chassis for Kepco controllers and displays a list of controllers found. If more than one is found, the user may select which one to connect to. Upon execution the Kepco controller will be initialized. See also [Initialize](#).

### A.2.2.3 Chanl



**KPTMAVXI Chanl.vi**

The Chanl function allows the selection of a power supply channel. All subsequent functions will be applied to that channel if no other is specified in the function itself.


### A.2.2.4 Close



**KPTMAVXI Close.vi**

The Close function terminates a programming session by closing the communication between the VXI slot 0 controller and the Kepco TMA VXI-27 power supply controller. It must be the last command issued. Failure to close the instrument may result in eventual out of memory errors.

### A.2.2.5 GetStatus



**KPTMAVXI Get Status.vi**

The GetStatus function reads information from various status registers and returns the result in STATUS as follows:

- Status Register values:
- 0 = Operation register
  - 1 = Questionable register

Status Type values:


- 0 = Event
- 1 = Condition
- 2 = Mask

### A.2.2.6 Initialize



The Initialize function may be used when AutoCon is not needed. It is a low level function which requires an Instrument Descriptor, which includes the logical address of the Kepco controller. It is recommended that [AutoCon](#) be used instead.


### A.2.2.7 Mode



The Mode function selects whether the power supply should operate in Constant Voltage or Constant Current mode. If the desired mode is not possible, because of the load, an overload condition will be set in the Questionable Status register.

mode values: 0 = voltage, 1 = current


### A.2.2.8 Outp



The Outp function closes or opens the output relay, on units which have relays. On units without relays, the output is Set to the last programmed value or Reset to 0.


output values: 0 = off, 1 = on

### A.2.2.9 Read



The Read function returns the output voltage and current of the power supply.

### A.2.2.10 Reset



The Reset function sets the power supply to its power on state. Voltage and current are set to 0, and relays are opened. If the channel # is set to 0, all power supplies are reset, otherwise, only the selected channel is reset.


### A.2.2.11 RevisionQuery



The RevisionQuery function returns the firmware revision of the Kepco TMA VXI-27 power supply controller and the revision of the Kepco Instrument driver.


See also [Vers](#).

### A.2.2.12 SelfTest




The SelfTest function opens all output relays, and programs all power supplies to their maximum levels, then resets the outputs to 0. If any errors in output occurred, the channel number of the failed supplies are returned, otherwise a 0 is returned. If failures occur, the Questionable Event register must be read from each failed channel, using the [GetStatus](#) function, to determine the cause of failure and to clear the SelfTest error. This does not apply to the currently selected channel, since the register value for that channel is automatically returned by the self test function itself.

### A.2.2.13 Set



The Set function sets the output voltage and current values of the power supply, as determined by the load. The load determines if the supply will be in Constant Voltage or Constant Current mode. See also [mode](#).

#### A.2.2.14 Vers



The Vers function returns the revision number of the power supply firmware, if a channel number is specified. If the channel is 0, the revision number of the Kepco TMA VXI-27 power supply controller is returned. For power supplies, the model of the supply is also returned.

### A.3 KNOWLEDGE BASE

The Knowledge Base file presents information regarding specific aspects of the Kepco TMA VXI-27, such as the instrument class, size and weight, the power consumption and the cooling requirements. It also includes graphic information, stored in a .BMP file, regarding the settings for the VXI logical address.

## APPENDIX B - SCPI COMMON COMMAND/QUERY DEFINITIONS

### B.1 INTRODUCTION

This appendix defines the IEEE 488.2 common commands and queries used with the MBT Power Supply controller. Common commands and queries are preceded by an asterisk (\*) and are defined and explained in Figures A-1 through A-14, arranged in alphabetical order. Table A-1 provides a quick reference of all IEEE 488.2 common commands and queries used in the MBT power supply controller.

**TABLE B-1. IEEE 488.2 COMMAND/QUERY INDEX**

COMMAND	PAR.	COMMAND	PAR.
*CLS	B.2	*RST	B.10
*ESE, ?	B.3, B.4	*SRE, ?	B.11, B.12
*ESR?	B.5	*STB?	B.13
*IDN?	B.6	*TRG	B.14
*OPC, ?	B.7, B.8	*TST?	B.15
*OPT	B.9	*WAI	B.16

### B.2 \*CLS — CLEAR STATUS COMMAND

**\*CLS**

Syntax: \*CLS

Description: **Clears status data.** Clears the error queue of the instrument. It also clears the following registers without affecting the corresponding Enable Registers: Standard Event Status Register (ESR), Operation Status Event Register, Questionable Status Event Register, and Status Byte Register (STB).  
 Related commands: \*OPC \*OPC?. (See example, Figure B-1.)

### B.3 \*ESE — STANDARD EVENT STATUS ENABLE COMMAND

**\*ESE**

Syntax: \*ESE <integer> where <integer> = positive whole number: 0 to 255 per Table B-2.  
 Default Value: 0

Description: **This command programs the standard Event Status Enable register bits.** The contents function as a mask to determine which events of the Event Status Register (ESR) are allowed to set the ESB (Event Summary Bit) of the Status Byte Register. Enables the Standard events to be summarized in the Status Byte register (1 = set = enable function, 0 = reset = disable function). All of the enabled events of the standard Event Status Enable register are logically ORed to cause ESB (bit 5) of the Status Byte Register to be set (1 = set = enable, 0 = reset = disable). (See example, Figure B-1.)

**TABLE B-2. STANDARD EVENT STATUS ENABLE REGISTER AND STANDARD EVENT STATUS REGISTER BITS**

CONDITION	PON	NU	CME	EXE	DDE	QUE	NU	OPC
BIT	7	6	5	4	3	2	1	0
VALUE	128	64	32	16	8	4	2	1

PON Power On  
 NU (Not Used)  
 CME Command Error  
 EXE Execution Error  
 DDE Device Dependent Error  
 QUE Query Error  
 OPC Operation Complete

### B.4 \*ESE? — STANDARD EVENT STATUS ENABLE QUERY

**\*ESE?**

Syntax: \*ESE? Return value: Integer> value per Table B-2.

Description: **Returns the mask stored in the Standard Event Status Enable Register.** Contents of Standard Event Status Enable register (\*ESE) determine which bits of Standard Event Status register (\*ESR) are enabled, allowing them to be summarized in the Status Byte register (\*STB). All of the enabled events of the Standard Event Status Enable Register are logically ORed to cause ESB (bit 5) of the Status Byte Register to be set (1 = set = enable function, 0 = reset = disable function). (See example, Figure B-1.)

## B.5 \*ESR? — EVENT STATUS REGISTER QUERY

# \*ESR?

Syntax: \*ESR?

Return value: <integer> (Value = contents of Event Status register as defined in Table B-2.)

Description: **Causes the power supply to return the contents of the Standard Event Status register. After it has been read, the register is cleared.** The Standard Event Status register bit configuration is defined in Table B-2(1 = set, 0 = reset). Related Commands: \*CLS, \*ESE, \*OPC. (See example, Figure B-1.)

## B.6 \*IDN? — IDENTIFICATION QUERY

# \*IDN?

Syntax: \*IDN?

Return value: Character string

Description: **Identifies the instrument.** This query requests identification. The string contains the manufacturer name, model, SN, firmware revs. The SN field is normally used for the serial #, but since serial #s are not stored in memory, the channel # is given instead. The firmware revision consists of the controller rev. and power module rev. separated by a '-'. If no module is present at the selected channel, PSC (Power Supply Controller) is given as the model. Supported models include MAT, MBT, and MST The character string contains the following fields: <Manufacturer>, <Model>, <Serial Number>, <Firmware revision> where: <Manufacturer> = KEPCO, <Model> = BOP, <Serial Number> = MM,DD,YY-SSS (MM - month, DD - day, YY - year, SSS - serial number in that day) <Firmware revision>=n.m (n.m revision, e.g, 1.0) (See example, Figure B-1.)

The model identified in the \*IDN? query after power up of the controller is the device connected to the BITBUS with an address of 1. If no device is set to be address 1 then the power up IDN string returned will contain the model identifier of PSC. The model identifier reflects the type of power supply at a specific BITBUS address. figure C-3 shows an example of the model identifier after specifying any device.

## B.7 \*OPC — OPERATION COMPLETE COMMAND

# \*OPC

Syntax: \*OPC

Description: **Causes power supply to set status bit 0 (Operation Complete) when pending operations are complete** This command sets Standard Event Status Register bit 0 (see Table B-2) to "1" when all previous commands have been executed and changes in output level have been completed. This command does not prevent processing of subsequent commands, but bit 0 will not be set until all pending operations are completed. (1 = set = enable function, 0 = reset = disable function). (See example, Figure B-1.) As an example, the controller sends command(s), then sends \*OPC. If controller then sends \*ESR?, the power supply responds with either a "0" (if the power supply is busy executing the programmed commands), or a "1" (if the previously programmed commands are complete). (See example, Figure B-1.)

## B.8 \*OPC? — OPERATION COMPLETE QUERY

# \*OPC?

Syntax: \*OPC?

Return value: <1> (ASCII) placed in output queue when power supply has completed operation.

Description: **Indicates when pending operations have been completed.**When all pending operations are complete (all previous commands have been executed and changes in output level have been completed) a "1" is placed in the Output Queue. Subsequent commands are inhibited until the pending operations are completed. \*OPC? is intended to be used at the end of a command line so that the application program can monitor the bus for data until it receives the "1" from the power supply Output Queue. (See example, Figure B-1.)

# \*OPT?

## B.9 \*OPT? — OPTIONS QUERY

Syntax: \*OPT?  
Returns string determined by power supply model.

Description: **Causes the power supply to return an ASCII string which defines the functionality of the power supply.** The functionality is defined as follows:

STRING DATA	MEANING
CAL	Support for CALibrate is present.
RL3	Hardware switch controlling remote/local is functional. Unit can be used to take measurements in local mode, but all other functions require the unit to be in remote mode (REN must be asserted).

*CLS	Power supply clears status data.
*ESE 60	Power supply enables bits 5, 4, 3 and 2, allowing command error, execution error, device dependent error and query error to set the Event Status Summary bit when an STB command is executed.
*ESE?	Returns 60, (value of the mask) verifying that bits 5, 4, 3 and 2 are enabled.
*ES	Unknown command will set command error (Bit 5).
*ESR?	Returns 32 (bit 5 set), indicating Command Error has occurred since the last time the register was read.
*IDN?	Controller returns character string: "KEPCO,MST,1,V3.0-3.0"
*OPC	Allows status bit 0 to be set when pending operations complete
VOLT 21;CURR 3	Sets output voltage to 21V, output current to 3A
*ESR	Returns 129 (128 + 1, power on, bit 7 = 1, operation complete, bit 1 = 1)
*ESR	Returns 0 (event status register cleared by prior *ESR?)
VOLT 15;CURR 5;*OPC?	Sets output voltage to 15V, output current to 5A, puts "1" on output bus when command operations are complete.
*RST	Power supply reset to power on default state.
*SRE 40	When ESB or QUES bits are set (Table B-3), the Request for Service bit will be set.
*SRE?	Returns the value of the mask (40).
*STB?	For example, the Power supply responds with 96 (64 + 32) if MSS and the Event Status Byte (Table B-3) summary bit have been set. The power supply returns 00 if no bits have been set.
VOLT 25	Power supply voltage commanded to 25V.
VOLT:TRIG 12	Programs power supply voltage to 12V when *TRG received.
INIT	Trigger event is initialized.
*TRG	Power supply reverts to commanded output voltage of 12V.
*TST?	Power supply executes self test and responds with 0 if test completed successfully, with 1 if test failed.

FIGURE B-1. GPIB COMMANDS

## B.10 \*RST — RESET COMMAND

# \*RST

Syntax: \*RST

Description: **Resets power supply to the power on default state.** The power supply is programmed to the power on values of the following parameters: CURR[:LEV][:IMM] = 0, VOLT[:LEV][:IMM] = 0, OUTP[:STAT] = OFF. If the power supply is in either an overvoltage or overcurrent state, this condition is reset by \*RST. (See example, Figure B-1.)

## \*SRE

### B.11 \*SRE — SERVICE REQUEST ENABLE COMMAND

Syntax: \*SRE<integer> where <integer> = value from 0 - 255 per Table B-3, except bit 6 cannot be programmed.

Description: **Sets the condition of the Service Request Enable register.** The Service Request Enable register determines which events of the Status Byte Register are summed into the MSS (Master Status Summary) and RQS (Request for Service) bits. RQS is the service request bit that is cleared by a serial poll, while MSS is not cleared when read. A "1" (1 = set = enable, 0 = reset = disable) in any Service Request Enable register bit position enables the corresponding Status Byte bit to set the RQS and MSS bits. All the enabled Service Request Enable register bits then are logically ORed to cause Bit 6 of the Status Byte Register (MSS/RQS) to be set. Related Commands: \*SRE?, \*STB?. (See example, Figure B-1.)

**TABLE B-3. SERVICE REQUEST ENABLE AND STATUS BYTE REGISTER BITS**

CONDITION	OPER	MSS RQS	ESB	MAV	QUES	ERR QUE	NU	NU
BIT	7	6	5	4	3	2	1	0
VALUE	128	64	32	16	8	4	2	1

OPER      Operation Status Summary  
MSS      Master Status Summary  
RQS      Request for Service  
ESB      Event Status Byte summary  
MAV      Message available  
QUES      QUESTIONable Status Summary  
ERR QUE    1 or more errors occurred (see PAR. C.44)  
NU      (Not Used)

### B.12 \*SRE? — SERVICE REQUEST ENABLE QUERY

## \*SRE?

Syntax: \*SRE?      Response: <integer> = value from 0 - 255 per Table B-3.

Description: **Reads the Service Enable Register.** Used to determine which events of the Status Byte Register are programmed to cause the power supply to generate a service request (1 = set = function enabled, 0 = reset = function disabled). Related Commands: \*SRE, \*STB?. (See example, Figure B-1.)

### B.13 \*STB? — STATUS BYTE REGISTER QUERY

## \*STB?

Syntax: \*STB?      Response: <integer> value from 0 to 255 per Table B-3.

Description: **Reads Status Byte Register without clearing it.** This Query reads the Status Byte Register (bit 6 = MSS) without clearing it (1 = set = function enabled, 0 = reset = function disabled). The register is cleared only when subsequent action clears all set bits. MSS is set when the power supply has one or more reasons for requesting service. (A serial poll also reads the Status Byte Register, except that bit 6 = RQS, not MSS; and RQS will be reset.) Related Commands: \*SRE, \*SRE?. (See example, Figure B-1.)

### B.14 \*TRG — TRIGGER COMMAND

## \*TRG

Syntax: \*TRG

Description: **Triggers the power supply to be commanded to preprogrammed values of output current and voltage.** When the trigger is armed (checked by examining WTG bit in Status Operational Condition register) \*TRG generates a trigger signal. The trigger will change the output of the power supply to the output voltage and current levels specified by VOLT:TRIG and CURR:TRIG commands and clear the WTG bit in the Status Operation Condition register. If INIT:CONT has been issued, the trigger subsystem is immediately rearmed for subsequent triggers, and the WTG bit is again set to 1. \*TRG or GET are both addressed commands (only devices selected as listeners will execute the command). Related Commands: ABOR, INIT, TRIG, CURR:TRIG, VOLT:TRIG. (See example, Figure B-1.)

### B.15 \*TST? — SELF TEST QUERY

## \*TST?

Syntax: \*TST?      Returned value: 0 or 1 (0 = pass test, 1 = fail test)





## APPENDIX C - SCPI COMMAND/QUERY DEFINITIONS

### C.1 INTRODUCTION

This appendix defines the SCPI subsystem commands and queries used with the MBT Power Supply controller. Subsystem commands are defined in PAR. C.2 through C.49, arranged in groups as they appear in the tree diagram, Figure 3-4. Table C-1 provides a quick reference of all SCPI subsystem commands and queries used in the Interface Card.

**TABLE C-1. SCPI SUBSYSTEM COMMAND/QUERY INDEX**

COMMAND	PAR.	COMMAND	PAR.
INIT[:IMM]	C.2	STAT:PRES	C.27
INIT:CONT, ?	C.3, C.4	STAT:QUES[:EVENT]?	C.28
INST:CAT?	C.5	STAT:QUES:COND?	C.29
INST:NSEL	C.6	STAT:QUES:ENAB, ?	C.30, C.31
INST:SEL	C.7, C.8	STAT:QUES:INST?	C.32
INST:STAT	C.9	STAT:QUES:INST1?	C.33
MEAS:CURR?	C.10	STAT:QUES:INST 2?	C.34
MEAS:VOLT?	C.11	STAT:QUES:INST:ENAB, ?	C.35, C.36
OUTP[:STAT], ?	C.12, C.13	STAT:QUES:INST1:ENAB, ?	C.37, C.38
[SOUR:]CURR[:LEV][:IMM][:AMP], ?	C.14, C.15	STAT:QUES:INST2:ENAB, ?	C.39, C.40
[SOUR:]CURR[:LEV]:TRIG[:AMP], ?	C.16, C.17	STAT:QUES:INST:ISUM?	C.41
[SOUR:]VOLT[:LEV][:IMM][:AMP], ?	C.18, C.19	STAT:QUES:INST:ISUM:ENAB, ?	C.42, C.43
[SOUR:]VOLT[:LEV]:TRIG[:AMP]?	C.20, C.21	SYST:ERR?	C.44
[SOUR:]FUNC:MODE	C.22	SYST:ERR:CODE?	C.45, C.46
STAT:OPER:COND?	C.23	SYST:LANG	C.47
STAT:OPER:ENAB, ?	C.24, C.25	SYST:SET	C.48
STAT:OPER[:EVENT]?	C.26	SYST:VERS?	C.49

### C.2 INITiate[:IMMEDIATE] COMMAND

### INIT[:IMM]

Syntax: Short Form: INIT[:IMM] Long Form: INITiate[:IMMEDIATE]

Description: **Enables a single trigger.** If INIT:CONT is OFF, then INIT[:IMM] arms the trigger system for a single trigger. If INIT:CONT is ON, then the trigger system is continuously armed and INIT[:IMM] is redundant. This command enables a single trigger. A GPIB <GET>, \*TRG or command completes the sequence. Upon receipt of the <GET> or \*TRG command, the power supply will return to the programmed values of voltage and current established by the VOLT:TRIG and CURR:TRIG commands. After a GPIB <GET> or \*TRG command has been received, subsequent GPIB <GET>, \*TRG commands have no effect unless preceded by INIT or INIT:CONT ON. Related Commands: <GET>, \*RST, \*TRG. (See example, Figure C-3.)

### C.3 INITiate:CONTinuous COMMAND

### INIT:CONT

Syntax: Short Form: INIT:CONT {ON | OFF} or {1 | 0} ( 1 = on, 0 = off)  
Long Form: INITiate:CONTinuous {ON | OFF} or {1 | 0} ( 1 = on, 0 = off)

Description: **INIT:CONT ON enables continuous triggers.; INIT:CONT OFF disables continuous triggers.** If INIT:CONT is OFF, then INIT[:IMM] arms the trigger system for a single trigger. If INIT:CONT is ON, then the trigger system is continuously armed and INIT[:IMM] is redundant. Executing \*RST command sets INIT:CONT to OFF. (See example, Figure C-3.)

#### C.4 INITiate:CONTInuous QUERY

### INIT:CONT?

Syntax: Short Form: INIT:CONT? Long Form: :INITiate:CONTInuous?  
Return Value: 1 or 0

Description: **Determines whether continuous triggers are enabled or disabled.** Power supply returns value of INIT:CONT flag: "1" = continuous triggers are enabled (INIT:CONT ON); "0" = continuous triggers disabled (INIT:CONT OFF). (See example, Figure C-3.)

#### C.5 INSTRument:CATalog QUERY

### INST:CAT?

Syntax: Short Form: INST:CAT? Long Form: :INSTRument:CATalog?  
Return Value: comma separated string with the instrument numbers found on the bitbus.

Description: Allows the host computer to determine what instruments are on the bitbus. Unlike the \*RST command, this command does not scan possible bitbus addresses to determine if the device is present. The list contains all channel numbers found and allows the host computer to determine if the power supplies are connected and powered-up (see Figure C-1).

*RST	Bitbus is scanned and all supplies are set to 0v, 0c, and Voltage mode
INST:CAT?	With three power supplies connected to the TMA VXI-27 Power Supply controller the TMA returns 1,2,3 if their addresses are set to 1, 2 and 3. *** User turns off supply 2.
INST:CAT?	TMA returns 1,3 *** User turns on supply 2
INST:CAT?	TMA returns 1,3
INST2	Channel 2 restored
INST:CAT?	TMA returns 1,2,3 *** User turns off supply 3
INST:CAT?	TMA returns 1,2
VOLT3 4;:SYST:ERR?	TMA returns "-240, Hardware not found" *** User turns on supply 3
VOLT3 4;:SYST:ERR?	Channel 3 restored
INST:CAT?	TMA returns 1,2,3

FIGURE C-1. USE OF INSTRument:CATalog QUERY

#### C.6 INSTRument[:NSElect] COMMAND

### INST:NSEL

Syntax: Short Form :INST:NSEL <val> Long Form: INSTRument:NSElect <val>

Description: **Selects power supply connected to channel number <VAL>; also brings off-line or "locked out" power supply to on-line status.** selects the instrument to which subsequent commands will be addressed until another channel is selected. Identical to INST:SEL command (see Figure C-2).

#### C.7 INSTRument[:SElect] COMMAND

### INST:SEL

Syntax: Short Form :INST:SEL <val> Long Form: INSTRument:SElect <val>

Description: **Selects power supply connected to channel number <VAL>; also brings off-line or "locked out" power supply to on-line status.** selects the instrument to which subsequent commands will be addressed until another channel is selected. The <value> following the command is the channel (node) number, from 1 to 31. This command is also used to bring a power supply on-line (i.e., the controller recognizes a power supply assigned to a selected channel). In cases where a fault has "locked out" a power supply (the controller no longer recognizes the power supply assigned to a channel), this command restores the power supply to the system. (See example, Figure C-2).)

### C.8 INSTRUMENT[:SELECT]? QUERY

## INST:SEL?

Syntax: Short Form :INST:SEL? Long Form: INSTRUMENT:SELEct ?  
Return value: <VAL> 1 to 31

Description: **Used to determine which channel selected.**

### C.9 INSTRUMENT:STATE COMMAND

## INST:STAT

Syntax: Short Form :INST:STAT <val> Long Form: INSTRUMENT:STATE <val>

Description: 0 (off) sets output to 0; 1 (on) restores output voltage and current. (see Figure C-2)

Note: Power Supply at address 1 is an MBT 25-14, address 2 is an MST 6-12, and address 4 is a BOP 100-1.	
*RST	Devices are located on the BITBUS (IEEE 1118) as noted above.
INST:SEL 1;*IDN?	Controller returns KEPCO,MBT,1,V4.2-3.0 (Channel 1 selected; device connected to BITBUS channel 1 is MBT 25-14, firmware version 3.0; TMA firmware version is 4.2).
INST:NSEL 2;*IDN?	Controller returns KEPCO,MST,2,V4.2-2.6 (Channel 2 selected; device connected to BITBUS channel 2 is MST 6-12, firmware version 2.6; TMA firmware version is 4.2).
VOLT? MAX	Controller returns 6.0E0 indicating a 6 volt unit (MST 6-12 at connected to channel 2).
VOLT4? MAX::INST:SEL?	Controller returns 1.0E2,4 indicating address 4 is selected and the device connected to BITBUS channel 4 (BOP 100-1) is a 100 volt unit.
*IDN?	Controller returns KEPCO,BOP,1,V4.2-1.1 (Device connected to BITBUS channel 4 is a BOP with BIT card firmware version 1.1; TMA firmware version is 4.2).
*RST;*IDN?	Controller returns KEPCO,MBT,1,V4.2-3.0 (Channel 1 selected; device connected to BITBUS channel 1 is MBT 25-14, firmware version 3.0; TMA firmware version is 4.2).
INST:SEL 3;*IDN?	Controller returns KEPCO,PSC,3,V4.2 (Channel 3 selected; unknown device connected to channel 3; TMA firmware version is 4.2).

FIGURE C-2. IDENTIFYING AND SELECTING DEVICES ON BITBUS

### C.10 MEASURE[:SCALAR]:CURRENT[:DC]? QUERY

## MEAS:CURRE?

Syntax: Short Form: MEAS[:SCAL]:CURR[:DC]? <boolean>  
Long Form: MEASURE[:SCALAR]:CURRENT[:DC]? <boolean>  
<boolean> = 0 or 1  
Return Value: <num\_value> (digits with decimal point and Exponent)

Description: **Measures actual current.** This query returns the actual value of output current (measured at the output terminals) as determined by the programmed value of voltage and current and load conditions. NOTE: The SCPI convention for this command allows the controller to establish the range and accuracy of the measurement if nn,nn is added after the question mark; the power supply accepts this format but sets the command warning bit (13) in the status questionable register and ignores the extra characters. (See example, Figure C-3.)

### C.11 MEASURE[:VOLTAGE] [:SCALAR] [:DC]? QUERY

## MEAS:VOLT?

Syntax: Short Form: MEAS[:SCAL]:VOLT[:DC]? <boolean>  
Long Form: MEASURE[[:SCALAR]:VOLTAGE[:DC]? <boolean>  
<boolean> = 0 or 1  
Return Value: <num\_value> (digits with decimal point and Exponent)

Description: **Measures actual voltage.** This query returns the actual value of output voltage (measured at the output terminals) as determined by the programmed value of voltage and current and load conditions.

NOTE: The SCPI convention for this command allows the controller to establish the range and accuracy of the measurement if nn,nn is added after the question mark; the power supply accepts this format but sets the command warning bit (13) in the status questionable register and ignores the extra characters. (See example, Figure C-3.)

### C.12 OUTPut[:STATe] COMMAND

## OUTP

Syntax: Short Form: OUTP[:STAT] <boolean> Long Form: OUTPut[:STATe] <boolean>  
<boolean>=(0 or OFF, 1 or ON)  
OUTP <boolean>(@n1,n2,n3) Open or close multiple channels, n1, n2, n3 = channel numbers  
OUTP <boolean>(@n1:n2) Open or close a range of channels, n1 = low, n2 = high channel number

Description: **Enables or disables the power supply output.** Upon power up the output is disabled (OUTP OFF), except for BOP power supplies which power up with the output enabled (OUTP ON). When OUTP OFF is executed, the programmed values of voltage and current are saved, then voltage and current are programmed to 0. When OUTP ON is executed, the power supply output is restored to the previously saved programmed values. The saved values of voltage and current can be viewed by VOLT? and CURR? queries. Related Commands: OUTP?. (See example, Figure C-3. Multiple channel examples: OUTP OFF(@5,7) closes channels 5 and 7, OUTP ON(@4:7) opens channels 4, 5, 6, and 7.

### C.13 OUTPut[:STATe] QUERY

## OUTP?

Syntax: Short Form: OUTP[:STAT]? Long Form: OUTPut[:STATe]?  
Return Value: <int\_value> (0 or 1)

Description: **Indicates whether power supply output is enabled or disabled.** Returns 0 if output disabled, returns 1 if output enabled. Related Commands: OUTP. (See example, Figure C-3.)

### C.14 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] COMMAND

## CURR

Syntax: Short Form: [SOUR:]CURR[:LEV][:IMM][:AMP] <exp\_value>  
Long Form: [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] <exp\_value>  
<exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Sets programmed current level at power supply output.** This command programs output current to a specific value; actual output current will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222, "Data out of range" is posted in output queue. (See example, Figure C-3.)

### C.15 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] QUERY

## CURR?

Syntax: Short Form: [SOUR:]CURR[:LEV][:IMM][:AMP]? MIN, MAX  
Long Form: [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude]? MIN, MAX  
Return Value:<exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Returns either the programmed value, maximum value, or minimum value of current.** The CURR? query returns the programmed value of current. Actual output current will depend on load conditions. The CURR?MAX query returns the maximum current allowed for a particular model. CURR? Returns programmed current value. CURR? MAX returns maximum current allowed for power supply. CURR? MIN returns minimum current allowed for power supply (always 0). Related Commands: CURR. (See example, Figure C-3.)

NOTE: Power supply assumed to be operating in constant voltage mode.

OUTP ON	Output enabled.
OUTP?	Power supply returns "1" (output enabled).
VOLT 21; CURR 1.5	Power supply output programmed to go to 21V, current limit 1.5A
INIT:CONT ON	Continuous triggers enabled.
INIT:CONT?	Power supply returns "1."
VOLT:TRIG 15;CURR:TRIG 3	Power supply output programmed to return to 15V, current limit 3A upon receipt of trigger.
*TRG	Power supply output returns to 15V,current limit 3A.
VOLT 21; CURR 5E-2	Power supply output programmed to go to 21V, current limit 0.05A
MEAS:VOLT?	If actual value of output voltage is 20.9V, power supply returns 2.09E+1.
MEAS:CURR?	If actual value of output current is 0.0483A, power supply returns 4.83E-2.
FUNC:MODE?	Returns VOLT if power supply operating in constant voltage mode, CURR for constant current mode.
CURR:TRIG?	Returns 3 (current value established by CURR:TRIG.
VOLT:TRIG?	Returns 15 (voltage value established by VOLT:TRIG.
*TRG	Power supply output returns to 21V, current limit 0.05A.
INIT:CONT 0	Triggers disabled.
INIT:CONT?	Power supply returns "0."
OUTP OFF	Output disabled.
OUTP?	Returns 0 (output disabled).
MEAS:VOLT?	Returns 0. (measured output voltage).
VOLT?	Returns 17. (programmed output voltage)/
CURR?	Returns 1.5 (programmed current)
CURR? MAX	Returns 4 (assuming maximum allowable current for power supply being addressed is 4A).
CURR? MIN	Returns 0 (minimum allowable current).
CURR?	Returns 1.5, indicating programmed current value = 1.5A.
SYST:VERS?	Returns 1997.0.

**FIGURE C-3. PROGRAMMING THE OUTPUT**

**C.16 [SOURCE:]CURRENT[:LEVEL]TRIGGERED[:AMPLITUDE] COMMAND CURR:TRIG**

Syntax: Short Form: [SOUR:]CURR[:LEV]:TRIG[:AMP] <exp\_value>  
 Long Form: [SOURCE:]CURRENT[:LEVEL]:TRIGGERED[:AMPLITUDE] <exp\_value>  
 <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Programs current value to be transferred to output by \*TRG commands.** Actual output current will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222,"Data out of range" is posted in output queue. Related Commands: CURR. (See example, Figure C-3.)

**C.17 [SOURCE:]CURRENT[:LEVEL]TRIGGERED[:AMPLITUDE]? QUERY CURR:TRIG?**

Syntax: Short Form: [SOUR:]CURR[:LEV]:TRIG[:AMP]?  
 Long Form: [SOURCE:]CURRENT[:LEVEL]:TRIGGERED[:AMPLITUDE]?  
 Return Value: <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Returns the current value established by CURR:TRIG command.** (See example, Figure C-3.)

NOTE: The power supply is assumed to be operating in constant voltage (cV) mode.	
VOLT 21; CURR 1.1	Power supply programmed to voltage limit 21V, 1.1A.
CURR?	Returns 1.1.
CURR 4.2	Power supply output current programmed to 3.3A, error message -301 posted.
CURR?	Returns 3.3.
	--- OVERCURRENT CONDITION (1 SECOND) OCCURS.
CURR?	Returns small value (approx. 1% of full scale current rating).
CURR 2.5	Power supply output current programmed to 2.5A
	--- OVERCURRENT CONDITION (1 SECOND) OCCURS.
(After 10 seconds)	
CURR?	Returns 2.5.

FIGURE C-4. PROGRAMMING CURRENT

**C.18 [SOURCE:] VOLTage[:LEVEL][:IMMEDIATE][:AMPLITUDE] COMMAND VOLT**

Syntax: Short Form: [SOUR:]VOLT[:LEV][:IMM][:AMP] <exp\_value>  
 Long Form: [SOURCE:]VOLTage[:LEVEL][:IMMEDIATE][:AMPLITUDE] <exp\_value>  
 <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Sets programmed voltage level at power supply output.** This command programs output voltage to a specific value; actual output voltage will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222, "Data out of range" is posted in output queue. (See example, Figure C-3.)

**C.19 [SOURCE:] VOLTage[:LEVEL][:IMMEDIATE][:AMPLITUDE]? QUERY VOLT?**

Syntax: Short Form: [SOUR:]VOLT[:LEV][:IMM][:AMP]? {MIN | MAX}  
 Long Form: [SOURCE:]VOLTage[:LEVEL][:IMMEDIATE][:AMPLITUDE]? {MIN | MAX}

Description: **Identifies programmed voltage, maximum allowable voltage, or minimum voltage (always 0).** The VOLT? query returns the programmed value of voltage. Actual output voltage will depend on load conditions. The VOLT?MAX query returns the maximum voltage allowed for a particular model (e.g., 25V for Kepeco's MST25-8DM). VOLT? MINReturns minimum voltage allowed for power supply (always 0). Related Commands: VOLT. (See example, Figure C-3)

**C.20 [SOURCE:] VOLTage[:LEVEL] TRIGgered[:AMPLITUDE] COMMAND VOLT:TRIG**

Syntax: Short Form: [SOUR:]VOLT[:LEV]:TRIG[:AMP] <exp\_value>  
 Long Form: [SOURCE:]VOLTage[:LEVEL]:TRIGgered[:AMPLITUDE] <exp\_value>  
 <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Programs voltage value to be transferred to output by \*TRG commands.** Actual output voltage will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222, "Data out of range" is posted in output queue. (See example, Figure C-3.)

**C.21 [SOURCE:] VOLTage[:LEVEL] TRIGgered[:AMPLITUDE]? QUERY VOLT:TRIG?**

Syntax: Short Form: [SOUR:]VOLT[:LEV]:TRIG[:AMP]?  
 Long Form: [SOURCE:]VOLTage[:LEVEL]:TRIGgered[:AMPLITUDE]?  
 Return Value: <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E+1 for 27.1

Description: **Returns value representing voltage value to be programmed by \*TRG command established by VOLT:TRIG command).** (See example, Figure C-3.)

**C.22 [SOURCE:] FUNCTION:MODE COMMAND****FUNC:MODE**

Syntax: Short Form: FUNC:MODE {VOLT | CURR}  
 Long Form: FUNCTION:MODE {VOLT | CURR}

Description: **Establishes the operating mode of the power supply.** VOLT = Constant Voltage mode (CV).  
 CURR = Constant Current mode (CC).

**C.23 STATus:OPERation:CONDition QUERY****STAT:OPER:COND?**

Syntax: Short Form: STAT:OPER:COND? Long Form: STATus:OPERation:CONDition?  
 Return Value: <int\_value> 0 to 1313 (256 + 512 + 1024).

Description: **Returns the value of the Operation Condition Register (see Table C-2).** The Operation Condition Register contains unlatched real-time information about the operating conditions of the power supply. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See example, Figure C-5.)

**TABLE C-2. OPERATION CONDITION REGISTER, OPERATION ENABLE REGISTER, AND OPERATION EVENT REGISTER BITS**

CONDITION	NU	CC	RLY	CV	NU	NU	NU	NU	CC - POWER SUPPLY IN CONSTANT CURRENT MODE
BIT	15-11	10	9	8	7 - 6	5	4 - 1	0	CV - POWER SUPPLY IN CONSTANT VOLTAGE MODE
VALUE	32,768 - 2048	1024	512	256	128 - 64	32	16 - 2	1	NU - NOT USED
									RLY - POWER SUPPLY RELAY IS CLOSED

**C.24 STATus:OPERation:ENABLE COMMAND****STAT:OPER:ENAB**

Syntax: Short Form: STAT:OPER:ENAB <int\_value> 0 to 1313 (1 + 32 + 256 + 1024)  
 Long Form: STATus:OPERation:ENABLE <int\_value> 0 to 1313 (1 + 32 + 256 + 1024)

Description: **Sets Operation Enable Register.** The Operation Enable Register is a mask for enabling specific bits in the Operation Event Register which will cause the operation summary bit (bit 7) of the Status Byte register to be set Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). The operation summary bit is the logical OR of all the enabled bits in the Operation Event register. (See example, Figure C-5.)

**C.25 STATus:OPERation:ENABLE? QUERY****STAT:OPER:ENAB?**

Syntax: Short Form: STAT:OPER:ENAB? Long Form: STATus:OPERation:ENABLE?  
 Return Value: <int\_value> 0 to 1313 (1 + 32 + 256 + 1024).

Description: **Reads Operation Enable Register (see Table C-2).** Returns value of Operation Enable Register bits. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See example, Figure C-5.)

**C.26 STATus:OPERation[:EVENT] QUERY****STAT:OPER?**

Syntax: Short Form: STAT:OPER[:EVENT]? Long Form: STATus:OPERation[:EVENT]?  
 Return Value: <int\_value> 0 to 1313 (1 + 32 + 256 + 1024).

Description: **Indicates changes in conditions monitored by Operational Event Register.** Returns the value of the Operation Event register. The Operation Event register is a read-only register which holds (latches) all events that occur. Reading the Operation Event register clears it. . (See example, Figure C-5.)

# STAT:PRES

## C.27 STATus:PRESet COMMAND

Syntax: Short Form: STAT:PRES Long Form: STATus:PRESet

Description: **Disables reporting of all status events.** This command sets all bits of the Operation Condition (Table C-2) and Questionable Condition Registers to 0, preventing all status events from being reported. (See example, Figure C-5.)

NOTE: The selected power supply is assumed to be operating in cV (constant voltage) mode.	
STAT:OPER:ENAB 1056	Mask enabled for CC, WTG and bits.
STAT:OPER:ENAB?	Returns 1056 (32 + 1024) (CC, WTG bits set).
STAT:QUES:ENAB 3	Mask enabled for OV and OC bits (1 + 2).
STAT:QUES:ENAB?	Returns 3 (1 + 2) indicating OV and OC bits are enabled.
STAT:PRES	Operation Condition and Questionable Condition registers are reset.
INIT:CONT ON	Continuous triggers enabled.
STAT:OPER:COND?	Power supply returns 288 (256 + 32) to indicate that power supply is constant voltage mode and Wait For Trigger is true.
STAT:OPER?	Returns 1057, e.g., indicating that since the last reading of the Operation Event Register the power supply has entered Constant Current mode, the Wait Trigger was set.
STAT:OPER?	Returns 0 indicating no changes since previous reading of the Operation Event register.
STAT:QUES?	Returns 0 (no questionable conditions occurred since previous reading
--- OVERCURRENT CONDITION OCCURS	
STAT:QUES?	Returns 2 (overcurrent protection tripped since the last STAT:QUES? query).
STAT:QUES:COND?	Returns 2, (Power supply still in overcurrent protection state).
STAT:QUES?	Returns 0, (Register cleared by previous STAT:QUES?).
STAT:QUES:COND?	Returns 2, (Power supply still in overcurrent protection state).
SYST:ERR?	Power supply returns 0, "No error" message.
INST:SEL 1	Select instrument 1
STAT:QUES?	TMA responds 4 indicating instrument 1 in current mode
INST:SEL 2	Select instrument 2
STAT:QUES?	TMA responds 8 indicating instrument 2 in voltage mode
STAT:QUES:INST:ISUM1?	TMA responds 4 indicating instrument 1 in current mode
STAT:QUES:INST:ISUM2?	TMA responds 8 indicating instrument 2 in voltage mode

FIGURE C-5. USING STATUS COMMANDS AND QUERIES

## C.28 STATus:QUESTionable[:EVENT]? QUERY

# STAT:QUES?

Syntax: Short Form: STAT:QUES[EVENT]? Long Form: STATus:QUESTionable[EVENT]?  
Return Value: <int\_value> actual register value

Description: **Indicates questionable events that occurred since previous STAT:QUES? query.** Returns the value of the Questionable Event register (see Table C-3). The Questionable Event register is a read-only register which holds (latches) all events. Reading the Questionable Event register clears it.

(See example, Figure C-5.)

**TABLE C-3. QUESTIONABLE EVENT REGISTER, QUESTIONABLE CONDITION REGISTER AND QUESTIONABLE CONDITION ENABLE REGISTER BITS**

CONDITION	PL	OL	RE	NU	NU	NU	NU	NU	OT	NU	CE	VE
BIT	11	10	9	8	7	6	5	4	3	2	1	0
VALUE	2048	1024	512	256	128	64	32	16	8	4	2	1

PL POWER LOSS  
 OL OVERLOAD  
 RE RELAY ERROR  
 OT OVERTEMPERATURE  
 CE CURRENT ERROR  
 VE VOLTAGE ERROR  
 NU NOT USED

**C.29 STATus:QUESTIONable:CONDition? QUERY STAT:QUES:COND?**

Syntax: Short Form: STAT:QUES:COND? Long Form: STATus:QUESTIONable:CONDition?  
 Return Value: <int\_value> actual register value

Description: **Returns the value of the Questionable Condition Register (see Table C-3).** The Questionable Condition Register contains unlatched real-time information about questionable conditions of the power supply. Bit set to 1 = condition (active, true); bit reset to 0 = condition (inactive, false). (See example, Figure C-5.)

**C.30 STATus:QUESTIONable:ENABle COMMAND STAT:QUES:ENAB**

Syntax: Short Form: STAT:QUES:ENAB <int\_value> Long Form: STATus:QUESTIONable:ENABle <int\_value>

Description: **Programs Questionable Condition Enable Register (see Table C-3).** The Questionable Condition Enable Register determines which conditions are allowed to set the Questionable Condition Register; it is a mask for enabling specific bits in the Questionable Event register that can cause the questionable summary bit (bit 3) of the Status Byte register to be set. The questionable summary bit is the logical OR of all the enabled bits in the Questionable Event register. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See example, Figure C-5.)

**C.31 STATus:QUESTIONable:ENABle? QUERY STAT:QUES:ENAB?**

Syntax: Short Form: STAT:QUES:ENAB? Long Form: STATus:QUESTIONable:ENABle?  
 Return Value: <int\_value> actual register value

Description: **Reads Questionable Condition Enable Register (see Table C-3).** Power supply returns value of Questionable Condition Enable Register, indicating which conditions are being monitored. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). Related Commands: STAT:QUES?. (See example, Figure C-5.)

**C.32 STATus:QUESTIONable:INSTrument? QUERY STAT:QUES:INST?**

Syntax: Short Form: STAT:QUES:INST? Long Form: STATus:QUESTIONable:INSTrument?  
 Return Value: <int\_value> actual register value

Description: **Reads Questionable Instrument Register 0 (see Table C-4).** Unit returns value of Instrument Register 0 (inst register). The bits of this register are set when at least one bit in the specified channel's ISUM register was set previously and the specific enable bit was also set. When this register is read, bits 1 -

14 are cleared. Bit 0 which indicates the summary of the bits in Instrument Register 1 (inst1 register) remains set until the inst1 register is read.

**TABLE C-4. QUESTIONABLE INSTRUMENT REGISTER 0 BITS**

CONDITION	NU	CH 14	CH 13	CH 12	CH 11	CH 10	CH 9	CH 8	CH 7	CH 6	CH 5	CH 4	CH 3	CH 2	CH 1	INST1
BIT	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
VALUE	32768	16384	8192	4096	2048	1024	512	256	128	64	32	16	8	4	2	1

CH CHANNEL  
 NU NOT USED  
 INST1 INSTRUMENT REGISTER 1

**C.33 STATUS:QUESTIONABLE:INSTRUMENT1? QUERY**

**STAT:QUES:INST1?**

Syntax: Short Form: STAT:QUES:INST1? Long Form: STATUS:QUESTIONABLE:INSTRUMENT1?  
 Return Value: <int\_value> actual register value

Description: **Reads Questionable Instrument Register 1 (see Table C-5).** Unit returns value of Instrument Register 1 (inst1 register). The bits of this register are set when at least one bit in the specified channel's ISUM register was set previously and the specific enable bit was also set. When this register is read, bits 1 - 14 are cleared. Bit 0 which indicates the summary of the bits in Instrument Register 2 (inst2 register) remains set until the inst2 register is read.

**TABLE C-5. QUESTIONABLE INSTRUMENT REGISTER 1 BITS**

CONDITION	NU	CH 28	CH 27	CH 26	CH 25	CH 24	CH 23	CH 22	CH 21	CH 20	CH 19	CH 18	CH 17	CH 16	CH 15	INST2
BIT	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
VALUE	32768	16384	8192	4096	2048	1024	512	256	128	64	32	16	8	4	2	1

CH CHANNEL  
 NU NOT USED  
 INST1 INSTRUMENT REGISTER 1

**C.34 STATUS:QUESTIONABLE:INSTRUMENT2? QUERY**

**STAT:QUES:INST2?**

Syntax: Short Form: STAT:QUES:INST2? Long Form: STATUS:QUESTIONABLE:INSTRUMENT2?  
 Return Value: <int\_value> actual register value

Description: **Reads Questionable Instrument Register 2 (see Table C-6).** Unit returns value of Instrument Register 2 (inst2 register). The bits of this register are set when at least one bit in the specified channel's ISUM register was set previously and the specific enable bit was also set. When this register is read, bits 1 - 14 are cleared.

**TABLE C-6. QUESTIONABLE INSTRUMENT REGISTER 2 BITS**

CONDITION	NU	CH 31	CH 30	CH 29	NU
BIT	15-4	3	2	1	0
VALUE	32768-16	8	4	2	1

CH CHANNEL  
 NU NOT USED

**STAT:QUES:INST:ENAB**

**C.35 STATUS:QUESTIONABLE:INSTRUMENT:ENABLE COMMAND**

Syntax: Short Form: STAT:QUES:INST:ENAB <int\_value>  
 Long Form: STATUS:QUESTIONABLE:INSTRUMENT:ENABLE <int\_value>

Description: **Programs Questionable Instrument Register 0 Enable Register (see Table C-3).** The Questionable Instrument Register 0 Enable Register is a mask which determines which channels are allowed to set Questionable Instrument Register 0.

## STAT:QUES:INST:ENAB?

### C.36 STATus:QUESTIONable:INSTRument:ENABLE QUERY

Syntax: Short Form: STAT:QUES:INST:ENAB?  
Long Form: STATus:QUESionable:INSTRument:ENABLE?  
Return Value: <int\_value> actual register value.

Description: **Reads Questionable Instrument Register 0 Enable Register (see Table C-3).** Unit returns value of Questionable Instrument Register 0 Enable Register.

## STAT:QUES:INST1:ENAB

### C.37 STATus:QUESTIONable:INSTRument1:ENABLE COMMAND

Syntax: Short Form: STAT:QUES:INST1:ENAB <int\_value>  
Long Form: STATus:QUESionable:INSTRument1:ENABLE <int\_value>

Description: **Programs Questionable Instrument Register 1 Enable Register (see Table C-3).**The Questionable Instrument Register 1 Enable Register is a mask which determines which channels are allowed to set Questionable Instrument Register 1.

## STAT:QUES:INST1:ENAB?

### C.38 STATus:QUESTIONable:INSTRument1:ENABLE? QUERY

Syntax: Short Form: STAT:QUES:INST1:ENAB? Long Form: STATus:QUESionable:INSTRument1:ENABLE?  
Return Value: <int\_value> actual register value.

Description: **Reads Questionable Instrument Register 1 Enable Register (see Table C-3).** Unit returns value of Questionable Instrument Register 1 Enable Register.

## STAT:QUES:INST2:ENAB

### C.39 STATus:QUESTIONable:INSTRument2:ENABLE COMMAND

Syntax: Short Form: STAT:QUES:INST2:ENAB <int\_value>  
Long Form: STATus:QUESionable:INSTRument2:ENABLE <int\_value>

Description: **Programs Questionable Instrument Register 2 Enable Register (see Table C-6).**The Questionable Instrument Register 2 Enable Register is a mask which determines which channels are allowed to set Questionable Instrument Register 2.

## STAT:QUES:INST2:ENAB?

### C.40 STATus:QUESTIONable:INSTRument2:ENABLE? QUERY

Syntax: Short Form: STAT:QUES:INST2:ENAB? Long Form: STATus:QUESionable:INSTRument2:ENABLE?  
Return Value: <int\_value> actual register value.

Description: **Reads Questionable Instrument Register 2 Enable Register (see Table C-3).** Unit returns value of Questionable Instrument Register 2 Enable Register.

### C.41 STATus:QUESTIONable:INSTRument:ISUM QUERY **STAT:QUES:INST:ISUM?**

Syntax: Short Form: STAT:QUES:INST:ISUM? Long Form: STATus:QUESionable:INSTRument:ISUM?  
Return Value: <int\_value> actual register value

Description: **Reads ISUM Register (see Table C-3).** Unit returns value of ISUM Register for selected channel This register is identical in function to the QUESTIONable register for the selected channel

## STAT:QUES:INST:ISUM:ENAB

### C.42 STATus:QUESTIONable:INSTRument:ISUM:ENABLE COMMAND

Syntax: Short Form: STAT:QUES:INST:ISUM:ENAB <int\_value>  
Long Form: STATus:QUESionable:INSTRument:ISUM:ENABLE <int\_value>

Description: **Programs Questionable Instrument ISUM Enable Register (see Table C-3).**The Questionable Instrument ISUM Enable Register is a mask which determines which conditions are allowed to set the Questionable Instrument ISUM Register for the selected channel.

## STAT:QUES:INST:ISUM:ENAB?

### C.43 STATus:QUESTIONable:INSTrument:ISUM:ENABle? QUERY

Syntax: Short Form: STAT:QUES:INST:ISUM:ENAB?  
Long Form: STATus:QUEsionable:INSTrument:ISUM:ENABle?  
Return Value: <int\_value> actual register value

Description: **Reads ISUM Enable Register (see Table C-3).** Unit returns value of ISUM Enable Register for selected channel.

### C.44 SYSTem:ERRor[:NEXT]? QUERY

## SYST:ERR?

Syntax: Short Form: SYST:ERR[:NEXT]? Long Form: SYSTem:ERRor[:NEXT]?  
Return Value: <int\_value,string>

Description: **Posts error messages to the output queue.** Returns the next error number followed by its corresponding error message string from the instrument error queue. The error queue is a FIFO (first in first out) buffer that stores errors as they occur. As it is read, each error is removed from the queue and the next error message is made available. When all errors have been read, the query returns 0,"No error". If more than 15 errors are accumulated, it will overflow. The oldest errors stay in the queue but the most recent errors are discarded. The last error in the queue will be -350,"Too many errors." Error messages are defined in Table C-7.

### C.45 SYSTem:ERRor:CODE? QUERY

## SYST:ERR:CODE?

Syntax: Short Form: SYST:ERR:CODE? Long Form: SYSTem:ERRor:CODE?

Description: Returns the three character error code without the ASCII definition string. The error codes are defined in table C-7 (See example, Figure C-3.)

### C.46 SYSTem:ERRor:CODE:ALL? QUERY

## SYST:ERR:CODE:ALL?

Syntax: Short Form: SYST:ERR:CODE:ALL? Long Form: SYSTem:ERRor:CODE:ALL?  
Return Value:

Description: Returns a comma-separated list of all error codes. A maximum of 15 codes will be returned; if the queue is empty, the power supply returns 0. The error codes are defined in table C-7

### C.47 SYSTem:LANGuage COMMAND

## SYST:LANG

Syntax: Short Form: SYST:LANG CIIL Long Form: SYSTem:LANGuage CIIL

Description: **This command allows the CIIL command language to be used to program the power supply.** (CIIL is included to provide compatibility with earlier Kepco equipment.) Once CIIL is selected, the CIIL command 'GAL' followed by the command 'SCPI' must be sent for the power supply to respond to SCPI commands.

**TABLE C-7. ERROR MESSAGES**

ERROR MESSAGE	EXPLANATION
0, "No error"	No error
-100, "Command error"	Command and data understood, but more information included which is not recognized.
-102, "Syntax error"	First 4 characters recognized, subsequent characters not recognized.
-103, "Invalid separator"	For example, VOLT.10 received instead of VOLT:10
-108, "Parameter Not Allowed Error"	Volt12 sequence, channel number is invalid
-109, "Missing parameter"	For example, VOLT instead of VOLT 21.
-111, "Header separator error"	Missing space between volt and value or ; missing
-113, "Undefined header"	First 4 characters could not be identified as legal command. For example, command VLT instead of VOLT
-120, "Numeric data error"	Expected number but other characters were detected
-121, "Invalid character in number"	Volt 1,500 ( comma not allowed)
-123, "Exponent too large"	Exponent E+3 or greater is invalid.
-141, "Invalid character data"	For example OUTP OFD or OUTP STOP instead of OUTP OFF
-150, "String data error"	Invalid characters were detected in numeric entry. For example E.1 instead of E+1 or 4d3 instead of 4.3.
-222, "Data out of range"	Value exceeds power supply rating
-223, "Data format error"	Multiple decimals in digit, Multiple E, etc.
-224, "Illegal parameter value"	For example, OUTP 2 instead of OUTP 1
-241, "Hardware missing"	Requesting device 2 status (INST:NSEL 2)
-350, "Queue overflow"	More than 15 errors are in queue.
-410, "Query interrupted"	New command sent before data from previous query read. Previous query data lost.
-430, "Query Deadlocked"	Over 255 characters received in single input string"

**C.48 SYSTem:SET COMMAND**

**SYST:SET**

Syntax: Short Form: SYSTem:SET {CM0 | CM1} Long Form: SYSTem:SET {CM0 | CM1}

Description: Sending SYST:SET CM1 sets the unit to operate in compatible mode and have all GPIB functions compatible with software version 1.2 and lower units. Sending SYST:SET CM0 sets the unit to be fully SCPI 1997 compliant.

**C.49 SYSTem:VERSion QUERY**

**SYST:VERS?**

Syntax: Short Form: SYST:VERS? Long Form: SYSTem:VERSion?  
Return Value: <int\_value>.<int\_value> (YYYY.V)

Description: **Identifies SCPI Version implemented.** Returns SCPI Version number: YYYY = year, V = Revision number for specified year (e.g 1997,0.).



## APPENDIX D - CIIL COMMAND DEFINITIONS

### D.1 INTRODUCTION

This appendix defines the CIIL commands used with the TMA VXI-27 Controller. Table D-1 provides a quick reference of all CIIL commands used in the TMA VXI-27.

**TABLE D-1. CIIL SUBSYSTEM COMMAND/QUERY INDEX**

COMMAND	PAGE	COMMAND	PAGE
CLS	D-4	OPN	D-4
CNF	D-4	RST	D-4
FNC	D-1	SET	D-3
FTH	D-2	SRN	D-3
GAL	D-6	SRX	D-3
INX	D-2	STA	D-5
IST	D-4		

FNC

- Syntax:** Stimulus mode: FNC DCS :CHnn <SET Command>  
 Sensor mode: FNC DCS <VOLT or CURR command> :CHnn
- Function:** This operator is used with either the SET command to program a power supply's output (stimulus mode), or with the VOLT and CURR commands to read its output settings (sensor mode).
- Description:** The first operand contains the three (3) letter mnemonic pertaining to the device on the control bus, in this case DCS (Direct Current Source). If a reading is being set up, the modifier VOLT or CURR follows. The next operand is used to select the specific channel of the device being programmed or read from. The MBT can control up to 27 power supplies/power modules with control bus addresses in the range of 1 to 31.
- Example:**
- |   |  |
|---|--|
| FNC DCS :CH12 SET VOLT 15<br>FNC DCS :CH12 SET CURR 3<br>FNC DCS VOLT :CH03<br>FNC DCS CURR :CH21 | Power supply at node address 12 commanded to 15V<br>Power supply at node address 12 commanded to 3A<br>Power supply at node address 3 returns value which represents actual output voltage<br>Power supply at node address 21 returns value which represents actual output current |
|---|--|

NOTE: Actual output voltage and current depends on whether output is enabled or disabled and load conditions

**FIGURE D-1. FNC — FUNCTION COMMAND**

---

# INX

- Syntax:** INX VOLT (initiate voltage reading)  
INX CURR (initiate current reading)
- Function:** Commences a data acquisition process in accordance with the preceding FNC command.
- Description:** The response to the INX command is a dynamic time-out value, unless a catastrophic error condition exists, in which case an error message will be returned. If the time-out value returned is not zero, this indicates the power supply's output voltage or current has not yet settled. A time delay should be observed before proceeding with the FTH command, or the command may be repeated until a zero value is returned, but the preceding FTH command must also be repeated.
- Example:** INX VOLT                      Power supply initiates voltage reading)  
FTH VOLT                      Power supply sends voltage reading to controller)

**FIGURE D-2. INX — INITIATE OP CODE COMMAND**

---

# FTH

- Syntax:** FTH VOLT (fetch voltage reading)  
FTH CURR (fetch current reading)
- Function:** Commands the previously designated power supply to return the requested data reading.
- Description:** This command must immediately follow an INX command. The value returned is the value of the output voltage or current, whichever was requested, unless a catastrophic error condition exists, in which case an error message will be returned. The value observed will be in scientific notation.
- Example:** INX VOLT                      Power supply initiates voltage reading)  
FTH VOLT                      Power supply sends voltage reading to controller)

**FIGURE D-3. FTH — FETCH COMMAND**

# SET, SRX, SRN

**Syntax:** FNC DCS :CHnn SET VOLT <value> CURL <value>  
FNC DCS :CHnn SET CURR <value> VLTL <value>  
SRX               Set Range Maximum  
SRN               Set Range Minimum

**Function:** This operator is used in conjunction with FNC (in stimulus mode) to specify the output mode of the power supply being programmed.

**Description:** The first operand is the noun modifier and the second operand specifies the value. The first operand field of the command contains the four(4) letter mnemonic for the output mode of the power supply. The choices are:

VOLT	VOLTAGE MODE OPERATION
VLTL	VOLTAGE LIMIT
CURR	CURRENT MODE OPERATION
CURL	CURRENT LIMIT

The second operand field of the command contains the value assigned to the chosen output mode. This value may be specified as accurately as the resolution of the power supply allows. It can be directly specified in ASCII integer, decimal, or in scientific notation.

There may be two (2) set commands, separated by a space (ASCII 32), for each power supply being programmed. The following are the only allowable combinations:

VOLT with CURL  
CURR with VLTL

The limit parameter (CURL or VLTL) may not be set without the main parameter. A polarity sign may precede the VOLT or CURR value so that the power supply's polarity may be selected.

In the case of Kepco's MBT power supplies, the two related Op Codes, SRX and SRN are functionally identical to the SET command, since there is only one range, 0 - maximum. The commands are included only for compatibility.

**Example:** FNC DCS :CH12 SET VOLT 5 CURL 3 Power supply at node address 12 commanded to 5V  
(Voltage mode) with current limit of 3A.  
FNC DCS :CH08 SET CURR 2 VLTL 17 Power supply at node address 8 commanded to 2A  
(Current mode) with voltage limit of 17V

FIGURE D-4. SET COMMAND

## OPN, CLS

<b>Syntax:</b>	OPN :CHnn CLS :CHnn
<b>Function:</b>	These commands are used to connect or disconnect the power supply from the load (effective for MR and MGR options only).
<b>Description:</b>	OPN                Disconnects the load from the power supply specified by the operand. CLS                Connects the load to the power supply specified by the operand.
<b>Example:</b>	OPN :CH22        Opens the relay of the power supply at node address 22. CLS :CH14        Closes the relay of the power supply at node address 14.

**FIGURE D-5. OPN, CLS — OPEN, CLOSE RELAY COMMANDS**

## RST

<b>Syntax:</b>	RST DCS :CHnn
<b>Function:</b>	This operator is used to return a power supply to its power-on state. The output voltage and current are programmed to zero and the output relay of MR and MGR models is opened.
<b>Example:</b>	RST DCS :CH13                The power supply at node address 13 is reset.

**FIGURE D-6. RST — RESET COMMAND**

## CNF, IST

<b>Syntax:</b>	CNF or IST
<b>Function:</b>	Causes power supply to execute confidence test.
<b>Description:</b>	The CNF operator commands the MBT to execute the confidence test procedure defined for the MBT power supplies (IST is functionally identical to CNF for MBT power supplies. The procedure consists of opening all power relays, programming voltage and current to their maximum values, switching polarity, checking for error flags, then programming voltage and current to zero. The results of CNF are obtained through the STA command.
<b>Example:</b>	CNF                All power supplies in the daisy chain execute confidence test. IST                All power supplies in the daisy chain execute self test.

**FIGURE D-7. CNF, IST — CONFIDENCE TEST, INTERNAL SELF TEST COMMANDS**

# STA

**Syntax:** STA

**Function:** Causes power supply to return operating status to controller.

**Description:** This operator commands the power supply to report its present operating status. Status is reported in the form of a message (character string) as defined below. Any catastrophic error conditions (indicated by \* in the table below) which exist will be reported, until the error condition is corrected. As required by CIIL, all error messages begin with an ASCII "F" (Fault) followed by a 2 digit code, "07" (Halt). The code that follows (SCSnn) indicates the type of device and the channel number. The next 3 digit code describes the nature of the fault: "DEV" for device related errors or "MOD" for non-device errors, such as syntax.

**TABLE D-2. CIIL ERROR MESSAGES**

ERROR MESSAGE	EXPLANATION
F07 DCSnn DEV Power Loss	The power supply has lost its input power. *
F07 DCSnn DEV Crowbarred (MAT, MBT)	A shutdown occurred due to overvoltage or overcurrent. *
F07 DCSnn DEV Device Turned Off (BOP)	
F07 DCSnn DEV Output Fault (MST)	
F07 DCSnn DEV Over Temperature	A shutdown occurred due to thermal causes. *
F07 DCSnn DEV Overload	The voltage or current limit point was exceeded. *
F07 DCSnn DEV Voltage Fault	The output voltage is not within limits (voltage mode). *
F07 DCSnn DEV Current Fault	The output current is not within limits (current mode). *
F07 DCSnn DEV Relay Not Opened	The power relay failed to open. *
F07 DCSnn DEV Relay Not Closed	The power relay failed to close. *
F07 DCSnn DEV Polarity Error	The output polarity is not correct. *
F07 DCSnn DEV Load Path Fault	Open or miswired load or error sense leads detected. *
F07 DCSnn MOD Invalid Command	Improper syntax was used. **
F07 DCSnn DEV Not Ready	The output voltage or current has not settled. **
F07 DCSnn DEV Device Not Present	The specified power supply was not present during power up or during the last DCL. **
F07 DCSnn DEV Device Not Responding	The power supply has failed to communicate to the controller. **
F07 DCSnn DEV Invalid Voltage Range	The programmed voltage is outside the power supply's range. **
F07 DCSnn DEV Invalid Current Range	The programmed current is outside the power supply's range. **
F07 DCSnn DEV Set Modifier Error	An improper SET command was sent. **
F07 DCSnn DEV Invalid Device ID	The selected channel was not between 1-31. **
*Catastrophic error	
**Non-Catastrophic error	

**FIGURE D-8. STA — STATUS COMMAND**

# GAL

**Syntax:** GAL

**Function:** Enables utility commands which change error handling defaults.

**Description:** This command enables the utility commands listed below. If no GAL command is issued, the default conditions are T0, F1, and P1. Once the GAL command is issued, the appropriate utility command may be sent to change the default condition.

**TABLE D-3. CIIL ERROR HANDLING UTILITY COMMANDS**

UTILITY COMMAND	DESCRIPTION
<b>T0</b>	Instructs non-catastrophic error messages to be erased from memory if any command is sent prior to STA command.
<b>T1</b>	Instructs non-catastrophic error messages to be stacked in memory until STA command is sent.
<b>F0</b>	Fetch Mode 0. Ignores error conditions when performing FTH command.
<b>F1</b>	Fetch Mode 1. Reports any error conditions which are present during FTH command.
<b>P0</b>	Power Loss Mode 0. Reports a power loss message only once until power is restored to the power module.
<b>P1</b>	Power Loss Mode 1. Continuously reports a power loss message until power is restored to the power module.

Note: The defaults are T0, F1 and P1

**Example:** GAL Enables utility commands.  
F0 Causes controller to ignore error conditions during FTH command.

**FIGURE D-9. GAL — GO TO ALTERNATE LANGUAGE COMMAND**

## APPENDIX E - GLOSSARY OF VXI TERMS

### E.1 INTRODUCTION

This appendix defines terms used in this manual which apply specifically to the VXIbus and VXI computer.

**BACKPLANE:** An assembly, typically a PCB, with 96 pin connectors and signal paths that bus the connector pins. VXIbus systems will have two sets of bussed connectors, called the J1 and J2 backplanes, or have three sets of bussed connectors, called the J1, J2 and J3 backplane.

**BOARD ASSEMBLY:** A board and its associated electrical components and connectors.

**COMMAND:** Any communication from a commander to a message based servant, consisting of a write to the servant's Data Low register, possibly preceded by a write to the Data High register.

**COMMANDER:** A message based device which has bus master capability and may have VXIbus servants under it in the system hierarchy. A Commander may act as a Servant to another Commander.

**DEVICE:** A component of an VXIbus system. Normally, a device will consist of one VXIbus board. However, multiple-slot devices and multiple-device module are permitted. Some examples of devices are computers, power supply controllers, multimeters, multiplexers, signal generators and counters.

**EVENTS:** Signals or interrupts generated by a device to notify another device of an asynchronous event.

**LOGICAL ADDRESS:** An 8 bit number which uniquely identifies each VXIbus Device in a system. It defines a device's A16 register addresses, and indicates Commander/Servant relationships.

**MAINFRAME:** A rigid framework that provides mechanical support for modules inserted into the backplane, ensuring that connectors mate properly and that adjacent modules do not contact each other. It also provides cooling airflow, and ensures that modules do not disengage from the backplane due to vibration or shock.

**MESSAGE BASED DEVICE:** An intelligent device which implements the defined VXIbus registers and communication protocols.

**MODULE:** Typically consists of a board assembly and its associated mechanical parts, front panel, optional shields, etc. A module contains everything required to occupy a slot in a mainframe. A module may occupy one or more slots.

**RESOURCE MANAGER:** A message based commander located at Logical Address 0 which provides configuration management services such as address map configuration, commander/servant mappings, self test and diagnostics management.

**RESPONSES:** Signals or interrupts generated by a device to notify another device of an asynchronous event. Response's contain the information in the sender's Response register.

**SERVANT:** A device that is controlled by a commander. There are message based and register based servants.

**SIGNAL:** Any communication between message based devices consisting of a write to a Signal register.

**SLOT:** A slot is a position where a module can be inserted into an VXIbus backplane. Each slot provides the 96 pin J connectors to interface with the board P connectors. It may have to provide one, two, or three connectors.

**SYSTEM:** A system consist of one or more mainframes that are connected, all sharing a common resource manager. Each device in a system has a unique Logical Address.

**TOP LEVEL:** A top level device has no commander; in the NORMAL OPERATION substate it may oerate autonomously with respect to all other devices except a device involved in runtime resource management. A device involved in runtime resource management retains the capability of forcing a top level device into the CONFIGURE sub-state by sensing tthe End Normal Operation or the Abort Normal Operation command to the top level device.

**VXIbus INSTRUMENT:** A VXIbus INSTRUMENT is defined to be a MESSAGE BASED DEVICE which supports the VXIbus Instrument protocols.

**VXIbus SUBSYSTEM:** A VXIbus Subsystem consists of a central timing module referred to as Slot 0 with up to 12 additional adjacent VXIbus modules.

**WORD SERIAL:** The simplest required communication protocol supported by Message Based devices in the VXIbus system. It utilizes the A16 communication registers to transfer data using a simple polling handshake method.

## APPENDIX F - SAMPLE PROGRAM

### F.1 INTRODUCTION

The following program, written in C language, is an example to illustrate communication with the TMA VXI-27. The program is written for LAB WINDOWS and for that reason some of the I/O functions are not standard C functions.

In order to communicate through the VXI specific hardware interface (in this case a National Instruments embedded slot 0 controller) a specific library NI-VXI is used.

The program contains examples of how to communicate to the register level and how to use the Word Serial Protocol which is supported by the TMA VXI-27.

The TMA VXI-27 supports events as interrupts; the sample program shows how to use the interrupt capabilities of the TMA VXI-27, even though they are not used in the LABVIEW library.

The program, after initializing the VXI library and testing that no interrupt lines are asserted, finds all TMA VXI-27's by looking for the manufacturer specific code (3804 hex for KEPCO INC.) If there is more than one TMA VXI-27 the program will prompt the user to select one, but if there is only one TMA VXI-27 the program goes on and does the following actions:

- do soft reset using the RESET BIT (bit 0) in control register
- check the PASSED bit
- check protocol register and response register
- execute the READ INTERRUPTERS command
- do BEGIN NORMAL OPERATION command
- send \*idn?

### F.2 DESCRIPTION

The TMA VXI-27 supports events as interrupts, however these interrupt capabilities are not used in the LAB VIEW library. The events which are supported are Request True and Request False. In order to check the interrupt capabilities on all levels from 1 to 7, the assign INTERRUPTER LINE command is used to connect the interrupter to level i from 1 to 7. The assignment is verified using the READ INTERRUPTER LINE command. Next, the interrupt on level i is routed to the signal handler and the signal interrupts are enabled. Now whenever there is a VXI interrupt on Level i it will be treated as a VXI signal and will be routed and added to the signal queue.

The program then sets the Event Status Enable and the Service Request Enable mask to a configuration which will generate an event when a wrong command is sent to the TMA VXI-27. By sending a wrong command \*sr we now generate REQT signal which is added to the signal queue. The WaitForSignal() function, if successful, acknowledges the receipt of the signal.

GetVXIbusStatus is then called to check the signals in the signal queue. If there are signals in the signal queue, the SignalDeq() function is called to dequeue them. Reading the Event Status Register generates REQF and resets the cause of the interrupt. REQF generates the interrupt and the REQF event signal is generated. The end of the program closes the VXI library.

```

/*****
*      Test Program for TMA VXI-27 using NI-VXI library      *
*****/

#include "c:\lw\include\formatio.h"

/* global variables */
char idn_buf[6],resp_buff[80],rp_buff[80];
int ret,ret_val1,cmmd,ret_val2,ret_val3,la_find,find_ret,slot,found,bb[12];
long prot_adr,vxi_adr,retcount;
int MySroutel; /* global variable for storing the routes */
int TestOk;

void main (void)
{

int i,adr_tst,fit,value,ret_value,controller,retval,levels,retsignal;
long modemask,signalmask,retsignalmask,timeout;

cls();
/* Initializes the VXI library at the begining of the application */
if (InitVXIlibrary() != 0){
    FmtOut("\n **ERROR in InitVXIlibrary TEST STOPED");
    exit(0); /* error in InitVXIlibrary */
}
else
FmtOut(" ***** TEST PROGRAM for the KEPCO TMA VXI-27 *****");

/* Test INTERRUPT LINES status */
ret = GetVXIbusStatusInd (-2, 5, &value);
if (value)
    FmtOut("\n **ERROR ** INTERRUPTS ASSERTED");

/* initialise TestOk variable */
TestOk = 1;
found=0;
fit = 0;
/* clear the table with all the TMA VXI-27 addresses found */
for (i=0;i<=11;i++){
    bb[i] = 0;
for (i=0;i<80;i++){
    resp_buff[i] = 0;
    rp_buff[i] = 0;
}
/* search for the TMA VXI-27 (manufacturer code 3804 hex) in all slots */
for (slot=1; slot<=12; slot++){
find_ret = FindDevLA ("", 3804, -1, -1, slot, -1, -1, &la_find);
if (find_ret == 0){
    FmtOut("%s<\n** Address for TMA VXI-27 from slot %i[w2] is %i[w3] "
,slot,la_find);
    bb[found] = la_find;
    found++;
}
else
FmtOut("%s< \nNot a TMA VXI-27 in slot %i[w2] ",slot);
}
if (found == 0)
FmtOut("\n***NO BITBUS_INTERFACES FOUND IN THIS MAINFRAME");
}
}

```

```

    if (found == 1){
FmtOut("\n**** Starting the Test Program for TMA VXI-27");
adr_tst = bb[0];
fit = 1;
    }

    while( fit == 0 ){
adr_tst = 0;
FmtOut("\n\rGive the Address of the TMA VXI-27 you want to test? ");
ScanIn("%s>%i",&adr_tst);
for(i=0;i<found;i++)
    if (adr_tst == bb[i])
        fit = 1;
    }
/* found bitbus interface at logical address adr_tst
The TEST PROGRAM will do the following actions:
-reset using bit 0 of register 4 the VXI interface
-verify fail inhibit bit - bit 1 of register 4
-free reset line, wait 10 seconds and test register 04 for PASSED BIT
-verify protocol register - offset 08 for 0xFFFF0 value
-verify response register - offset 0A for 0x4BFF value
-send Read Protocol command and test result 0x8623
-send again Read Protocol command without taking the result simulating a
multiple query error - used Read Protocol Error to verify the ERROR
-send Read Interrupters
*/

vxi_adr = 0xc000L + adr_tst*64 + 4;

/* do soft reset - SET RESET BIT (bit 0) in control register */
ret_value = VXIout(0x1,vxi_adr,2,0x1);

ret_value = VXIinReg(adr_tst,04,&value);
/* FmtOut("%s<\n Value with high level function = %x[w4]",value); */
if (value != 0x7f03){
FmtOut("\n **ERROR 05** SYSreset do not function");
TestOk = 0;
}
ret = GetVXIbusStatusInd (-2, 2, &value);
if (value == 0){
    FmtOut("\n **ERROR 06** SYSFAIL line on P1-C10 not active after RESET");
    TestOk = 0;
}

/* Deactivate reset line */
ret_value = VXIout(0x1,vxi_adr,2,0x0);
/* wait 10 seconds */
delay(10);

ret_value = VXIin(0x1,vxi_adr,2,&value);
if (value != 0x7F07){
FmtOut("\n **ERROR 08** the PASSED bit (U36B) is not set");
TestOk = 0;
}

if(TestOk){
/* read protocol register at offset 08 */
vxi_adr = vxi_adr + 4;
ret_value = VXIin(0x1,vxi_adr,2,&value);

```

```

if (value != 0xFFFF0){
    FmtOut("%s<\n **ERR 09** The protocol reg. is %x instead of fff0"
    ,value);
    TestOk = 0;
}
}

if(TestOk){
/* read response register at offset 0A */
vxi_adr = vxi_adr + 2;
prot_adr = vxi_adr;
ret_value = VXIin(0x1,prot_adr,2,&value);
if (value != 0x4BFF){
    FmtOut("%s<\n **ERR 10** The protocol reg. is %x instead of 4bff"
    ,value);
    TestOk = 0;
}
}
/* begin writing commands and reading back results */
vxi_adr = vxi_adr + 4;

if(TestOk){
/* now execute READ INTERRUPTERS command */
ret_value = WScmd(adr_tst,0xcaff,1,&value);
if (value != 0xfff9){
    FmtOut("%s<\n **ERR 15** result of RD_INT. cmmnd %x instead of fff9"
    ,value);
    TestOk = 0;
}
}

if(TestOk){
/* do BEGIN NORMAL OPERATION command */
ret_value = WScmd(adr_tst,0xfcff,1,&value);
if (value != 0xfffe){
    FmtOut(
    "%s<\n **ERR 17** BEG_NORMAL_OPER. result is %x instead of fffe"
    ,value);
    TestOk = 0;
}
/* test READY BIT SET in response register after BEGIN NORMAL OPERATION */
delay(1);
ret_value = VXIinReg(adr_tst,04,&value);
/* FmtOut("%s<\n Value with high level function = %x[w4]",value); */
if (value != 0x7f0f){
    FmtOut(
    "%s<\n **ERR 18 ** NOT READY after BEG_NORMAL_OPER. %x[w4]"
    ,value);
    TestOk = 0;
}
}

/* prepare *idn? command in idn_buf */
CopyString (idn_buf, 0, "*idn?", 0, 5);

if(TestOk){
/* write *idn? */
ret_value = WSrwt(adr_tst,idn_buf,5L,3,&retcount);
if (ret_value < 0){

```

```

        FmtOut("%s<\n Value of ret_value = %x[w4]",ret_value);
        TestOk = 0;
    }
    if (retcount != 5)
        FmtOut("%s<\n length= %i[b4w4] instead of 5",retcount);
    }

if(TestOk){
    /* put in resp_buff the answer */
    ret_value = WSrd(adr_tst,resp_buff,77L,1,&retcount);
    if (ret_value < 0){
        FmtOut("%s<\n Value of ret_value = %x[w4]",ret_value);
        TestOk = 0;
    }
}

if(TestOk){
/*****
    The following code will test the VXI
    interrupts on Levels 1-7 as a VXI signal.
*****/
for(i=1;i<=7;i++){
    /* now execute ASSIGN INTERRUPTER LINE command to level i */
    cmmd = 0xaa10 + i;
    ret_value = WScmd(adr_tst,cmmd,1,&value);
    if (value != 0xfffe){
        FmtOut(
            "%s<\n **ERR 20 ASGN_INT_LINE result is %x instead of fffe"
            ,value);
        TestOk = 0;
    }
}

if(TestOk){
    /* use READ INTERRUPTER LINE to verify the assignment */
    ret_value = WScmd(adr_tst,0x8D01,1,&value);
    if (ret_value < 0){
FmtOut(
"%s<\n **ERR 22 RD_INT_LINE result is %x instead of 0"
,ret_value);
TestOk = 0;
    }
    ret_value = (value)&(7);
    FmtOut("%s<\n **interrupter connected to IRQ%x ",ret_value);

    /* The following code routes level i to Signal handler and
    the rest to the VXI interrupt Handler */
    controller = -1;
    MySroute = (1 << (i-1));
    retval = RouteVXIint(controller, MySroute);

    /* The following code enables VXI interrupts for level i */
    levels = (1 << (i-1));
    retval = EnableVXItoSignalInt(controller,levels);

    /* now whenever there is a VXI interrupt on Level i it will be
    treated as a VXI signal and will be handled as indicated by
    the RouteSignal function. All the signals from the tested
    logical address are enqueued on the signal queue and none
    are handled by the signal handler */

```

```

modemask = 0L;
retval = RouteSignal(adr_tst, modemask);

/* The following code enables the signal interrupts */
retval = EnableSignalInt();

/* now generate REQT signal by enabling command error event and
sending an eronous command *sr */
CopyString (rp_buff, 0, "*ese 32", 0, 7);
ret_val1 = WSwrt(adr_tst,rp_buff,7,3,&retcount);
if(ret_val1 < 0){
FmtOut("%s<\n ** ERR 24 ret_value from *ese 32 = %x[w4]"
,ret_val1);
FmtOut("%s<\n returned message length= %i[b4w4]",retcount);
TestOk = 0;
}
CopyString (rp_buff, 0, "*sre 32", 0, 7);
ret_val1 = WSwrt(adr_tst,rp_buff,7,3,&retcount);
if(ret_val1 < 0){
FmtOut(
"%s<\n ** ERR 26 ret_value1 from *sre 32 = %x[w4]"
,ret_val1);
FmtOut("%s<\n returned message length= %i[b4w4]",retcount);
TestOk = 0;
}
/* now send an eronous message *sr to generate an error */
CopyString (rp_buff, 0, "*sr ", 0, 4);
ret_val1 = WSwrt(adr_tst,rp_buff,4,3,&retcount);
if(ret_val1 < 0){
FmtOut("%s<\n ** ERROR ret_value1 from *sr = %x[w4]"
,ret_val1);
FmtOut("%s<\n length= %i[b4w4]",retcount);
TestOk = 0;
}

/* now whenever there is a VXI signal from the tested
logical address the signal will be enqueued on the signal
queue. The WaitForSignal() function,if successful, dequeues
the signal. We call GetVXIbusStatus to check the signals in
the signal queue. If there are signals in the signal queue,
we call SignalDeq() function to dequeue them. If the
signal queue gets full the signal interrupts as well as the
VXI interrupts which are mapped to signals are disabled. */

/* The following code waits for REQT signal */
signalmask = 0x0200L; /* REQT bit set */
timeout = 1000L; /* wait for 1 second */
retval = WaitForSignal(adr_tst, signalmask, timeout,
&retsignal, &retsignalmask);

if (retval){
FmtOut(
"%s<\n **ERR - TIMEOUT waiting for REQT on level = %i",i);
TestOk = 0;
}

/* now generate request false signal by reading the event
status register */
CopyString (rp_buff, 0, "*esr?", 0, 5);

```

```

        ret_val1 = WSwrt(adr_tst,rp_buff,0x5L,3,&retcount);
        if(ret_val1 < 0)
FmtOut(
"%s<\n **ERR ret_value from *esr? = %x[w4]",ret_val1);
        else
ret_val1 = WSrd(adr_tst,rp_buff,0x10L,1,&retcount);
        /* The following code waits for REQF signal */
        signalmask = 0x0400L; /* REQF bit set */
        timeout = 1000L; /* wait for 2 seconds */
        retval = WaitForSignal(adr_tst, signalmask, timeout,
&retsignal, &retsignalmask);
        /* test if signal received within the specified period */
        if (retval == 0)
FmtOut(" - Ok");
        else{
FmtOut("%s<\n ** TIMEOUT waiting for REQF on level = %i",i);
TestOk = 0;
        }
        /* test if one of the interrupt lines are still asserted */
        ret = GetVXIbusStatusInd(-2, 5, &value);
        if (value)
FmtOut("\n **ERROR ** INTERRUPTS ASSERTED");
        } /* internal TestOk end - executed for i=1 thru 7 */
        } /* for end */
    } /* external TestOk end */

/* close the VXI library at the end of application */
CloseVXIlibrary();

}

```

