

INSTRUCTION SHEET



KEPCO An ISO 9001 Company.

RFP

INSTALLATION INSTRUCTIONS

FILLER PANEL MODELS

**RFP 19-12, RFP 19-16, RFP 19-18, RFP 19-24, RFP 19-26,
RFP 19-28, RFP 19-38, RFP 19-48, RFP 19-124**

Kepeco Filler Panel Models listed above are to be used with RA 19-3B, RA 19-4B, RA 19-5B, RA 19-6B, RA 19-7B and RA 19-8B Rack Adapters. Table 1 lists the dimensions of the filler panels. Attach to rack adapter chassis using hardware supplied.

TABLE 1. FILLER PANEL DIMENSIONS

MODEL	FILLER PANEL	WIDTH (in.)	HARDWARE
RFP 19-12	1/12 RACK	1.407	2 Screws, 2 Washers
RFP 19-16	1/6 RACK	2.847	2 Screws, 2 Washers
RFP 19-18	1/8 RACK	2.125	2 Screws, 2 Washers
RFP 19-24	1/24 RACK	0.704	See Note 6.
RFP 19-26	1/3 RACK	5.727	4 Screws, 4 Washers
RFP 19-28	1/4 RACK	4.286	4 Screws, 4 Washers
RFP 19-38	3/8 RACK	6.445	4 Screws, 4 Washers
RFP 19-48	1/2 RACK	8.600	4 Screws, 4 Washers
RFP 19-124	1/24 RACK	0.704	2 Screws, 2 Washers (See Note 7.)

NOTES:

1. Material: Aluminum 6061-T6, Finish: Kepeco Gray
2. Height: 5.218 in.
3. Thickness: 0.090 in.
4. Screws: #6-32 x 0.312 in., Phillips Pan Head (Kepeco P/N 101-0303)
5. Washers: Nylon #6 (Kepeco P/N 103-0107)
6. RFP 19-24 attaching hardware is an integral part of the panel. To install, first loosen the two thumbscrews (rotate counterclockwise). Mount the RFP 19-24 so the back of the panel is flush with the rack adapter, and the vertical edges are aligned with the adjacent power supply or the edge of the rack adapter, then tighten the thumbscrews. To remove the panel, loosen the two thumbscrews.
7. Used on RA 19-5B only.